

**38. No power coming, but woofer amplifier not operating.****INSPECTION PROCEDURE**

**1** Is tape player operating normally?

**Yes**

**Radio receiver assembly faulty.**

**No**

**2** Check if RADIO No. 2 fuse is OK?

**NG**

**Replace fuse.**

**OK**

**3** Is power supplied to ACC terminal of stereo component amplifier?

**No**

**ACC wire harness faulty.**

**YES**

**4** Check if RADIO No.1 fuse is OK?

**NG**

**Replace fuse.**

**OK**

**5** Is power supplied to +B terminal of stereo component amplifier?

**No**

**+B wire harness faulty.**

**YES**

**6** Check if GND (wire harness side) of radio receiver assembly grounded normally.

**NG**

**GND faulty.**

**OK**

**7** Is power supplied to ACC terminal of radio receiver assembly?

**No**

**Stereo component amplifier faulty.**

**YES**

**8** Is power supplied to +B terminal of radio receiver assembly?

**No**

**Stereo component amplifier faulty.**

**YES**

**9** Check if GND (wire harness side) of radio receiver assembly grounded normally.

**NG**

**GND faulty.**

**OK**

**10 Does continuity exist in speaker wire harness?**

**No**

**Speaker wire harness faulty.**

**YES**

**11 Temporarily install another speaker. Functions OK?**

**Yes**

**Speaker faulty.**

**No**

**12 Hiss noise from speaker?**

**No**

**Stereo component amplifier faulty.  
Recheck system after repair.**

**YES**

**Radio receiver assembly faulty. Recheck system after repair.**