



INSPECTION

INSPECT CAMSHAFT OIL CONTROL VALVE OPERATION

Connect the positive (+) lead from the battery to terminal 1 and negative (-) lead to terminal 2, and check the movement of the valve.

Battery positive voltage is applied	Valve moves in  direction
Battery positive voltage is cut off	Valve moves in  direction

If operation is not as specified, replace the valve.