

<b>DTC</b>	<b>B1221 / 21</b>	<b>Power window switch circuit on driver door</b>
------------	-------------------	---

<b>DTC</b>	<b>B1222 / 22</b>	<b>Door lock switch circuit on driver door</b>
------------	-------------------	--

<b>DTC</b>	<b>B1223 / 23</b>	<b>Power window switch circuit on passenger door</b>
------------	-------------------	--

<b>DTC</b>	<b>B1224 / 24</b>	<b>Door lock switch circuit on passenger door</b>
------------	-------------------	---

<b>DTC</b>	<b>B1225 / 25</b>	<b>Power window switch circuit on rear right door</b>
------------	-------------------	---

<b>DTC</b>	<b>B1226 / 26</b>	<b>Power window switch circuit on rear left door</b>
------------	-------------------	--

<b>DTC</b>	<b>B1241 / 41</b>	<b>Body No.1 ECU switch circuit diagnosis</b>
------------	-------------------	---

<b>DTC</b>	<b>B1252 / 52</b>	<b>Body No.2 ECU switch circuit diagnosis</b>
------------	-------------------	---

## CIRCUIT DESCRIPTION

These DTC notify how switch works as follows:

If DTC is not output when operating switch, it means failure of switch contact. If DTC is output when not operating switch, it means stick of switch. When something wrong is found by this diagnosis, inspect each switch. Then, replace the switch if there is a problem, or check the wireharness if there is no problem.

DTC No.	DTC Detecting Condition	Trouble Area
B1221/21	Stick of either of the power window master switch (except window lock switch)	<ul style="list-style-type: none"> <li>• Power window master switch</li> <li>• Wireharness</li> </ul>

B1222/22	Stick of door key lock and unlock switch	<ul style="list-style-type: none"> <li>• Door lock control switch</li> <li>• Door key lock and unlock switch</li> <li>• Wireharness</li> </ul>
B1223/23	Stick of power window switch or door lock control	<ul style="list-style-type: none"> <li>• Power window switch</li> <li>• Door lock control switch</li> <li>• Wireharness</li> </ul>
B1224/24	Stick of door key lock and unlock switch	<ul style="list-style-type: none"> <li>• Door lock control switch</li> <li>• Door key lock and unlock switch</li> <li>• Wireharness</li> </ul>
B1225/25	Stick of power window switch	<ul style="list-style-type: none"> <li>• Power window switch</li> <li>• Wireharness</li> </ul>
B1226/26	Stick of power window switch	<ul style="list-style-type: none"> <li>• Power window switch</li> <li>• Wireharness</li> </ul>
B1241/41	Stick of switch	<ul style="list-style-type: none"> <li>• Luggage compartment door opener switch</li> <li>• Luggage compartment door lock and unlock switch</li> <li>• Wireharness</li> </ul>
B1252/52	Stick of switch	<ul style="list-style-type: none"> <li>• Step light switch</li> <li>• Wireharness</li> </ul>

**HINT:**

Please refer to BE section for switch inspection, and to each door system of DI section for wireharness inspection.