

DTC	B1422/22	Compressor Lock Sensor Circuit
-----	----------	--------------------------------


CIRCUIT DESCRIPTION

This sensor sends 4 pulses per engine revolution to the engine and ECT ECU.

If the number ratio of the compressor speed divided by the engine speed is smaller than a predetermined value, the engine and ECT ECU turns the compressor OFF. And, the indicator flashes at about 1 second intervals.


DTC No.	Detection Item	Trouble Area
B1422/22	All conditions below are detected for 3 secs. or more (a) Engine speed : 450rpm or more (b) Ratio between engine and compressor speed deviates 20% or more in comparison to normal operation.	<ul style="list-style-type: none"><li>• Compressor.</li><li>• Compressor drive belt.</li><li>• Compressor lock sensor.</li><li>• Harness and connector between compressor and engine and ECT ECU</li><li>• Harness and connector between engine and ECT ECU and A/C control assembly</li><li>• Engine and ECT ECU</li><li>• A/C control assembly.</li></ul>

WIRING DIAGRAM



## INSPECTION PROCEDURE

## 1 Check voltage between terminal LOCKI of engine and ECT ECU and body ground.

**CHECK:**

- (a) Start engine.
- (b) Push AUTO SW.
- (c) Measure voltage between terminal LOCKI of engine and ECT ECU connector and body ground when A/C switch is ON.

**OK:**


Voltage 10 – 14 V

OK

Proceed to next circuit inspection shown on problem symptoms table (See page DI-912).

NG

## 2 Check compressor lock sensor.

**PREPARATION:**

- (a) Jack up the vehicle.
- (b) Disconnect compressor lock sensor connector.

**CHECK:**

Measure resistance between terminals 1 and 2 of compressor lock sensor connector.

**OK:**

Resistance

at 20°C (68°F) 990 – 1210 Ω

at 100°C (212°F) 1280 – 1550 Ω

NG

Replace compressor lock sensor.

OK

## 3 Check harness and connectors between engine and ECT ECU and compressor lock sensor. (See page IN-29).

NG

Repair or replace harness or connector.

OK

4

Check harness and connectors between engine and ECT ECU and A/C control assembly. (See page IN-29).

NG

Repair or replace harness or connector.

OK

Check and replace engine and ECT ECU and A/C control assembly.