

DIAGNOSTIC TROUBLE CODE CHART

If a malfunction code is displayed during the DTC check, check the circuit listed for that code in the table below and proceed to the appropriate page.

DTC No. (See Page)	Circuit Inspection	Trouble Area
P5001/ 21, 23 (DI-547)	Vehicle Speed Signal Abnormal	<ul style="list-style-type: none"><li>• Harness or connector between Engine and ECT ECU and vehicle speed sensor</li><li>• Vehicle speed sensor</li><li>• Engine and ECT ECU</li></ul>
P5201/ 52 (DI-548)	Short in Stop Light Switch Circuit	<ul style="list-style-type: none"><li>• Stop light switch</li><li>• Harness or connector between Engine and ECT ECU and stop light switch circuit</li><li>• Engine and ECT ECU</li></ul>
P5661/ 54 (DI-552)	Input Signal Circuit	<ul style="list-style-type: none"><li>• Engine and ECT ECU</li></ul>