

INSTALLATION

1. INSTALL DUST COVER


2. INSTALL INTERMEDIATE SHAFT ASSEMBLY

Temporarily tighten the bolt A.

3. INSTALL STEERING COLUMN ASSEMBLY

(a) Torque the 4 column assembly set nuts.


Torque: 25 N·m (260 kgf·cm, 19 ft·lbf)



(b) Tighten the hole cover clamp.

(c) Install the brake pedal return spring.

(d) Connect the connectors.



4. CONNECT INTERMEDIATE SHAFT ASSEMBLY

(a) Align the matchmarks on the intermediate shaft and control valve shaft.

(b) Torque the bolt B.

Torque: 35 N·m (360 kgf·cm, 26 ft·lbf)

(c) Torque the bolt A.

Torque: 35 N·m (360 kgf·cm, 26 ft·lbf)

5. INSTALL HEATER TO REGISTER DUCT NO.7

Tighten the nut.

6. INSTALL NO.1 SAFETY PAD

(a) Tighten the 4 pad set bolts and screw.

(b) Connect the hood lock release lever to the panel and tighten the 2 screws.

7. INSTALL FINISH PLATE AND END PAD

8. INSTALL NO.1 UNDER COVER

(a) Connect the connectors.

(b) Install the DLC3.

(c) Tighten the 3 screws.

9. INSTALL SPIRAL CABLE

(See page BE-35)

10. INSTALL COMBINATION SWITCH WITH SPIRAL CABLE


(a) Tighten the 3 screws.

(b) Connect the airbag connector.

(c) Connect the 4 connectors.

11. INSTALL UPPER AND LOWER COLUMN COVERS

Tighten the 3 screws.

**12. CENTER SPIRAL CABLE**

- (a) Check that the front wheels are facing straight ahead.
- (b) Turn the cable counterclockwise by hand until it becomes harder to turn the cable.
- (c) Then rotate the cable clockwise about 3 turns to align the mark.

HINT:

The cable will rotate about 3 turns to either left or right of the center.

13. INSTALL STEERING WHEEL


- (a) Align the matchmarks on the wheel and main shaft.
- (b) Torque the wheel set nut.

Torque: 35 N·m (360 kgf·cm, 26 ft·lbf)

- (c) Connect the connector.

14. INSTALL STEERING WHEEL PAD**NOTICE:**

- **Make sure the wheel pad is installed to the specified torque.**
- **If the wheel pad has been dropped, or there are cracks, dents or other defects in the case or connector, replace the wheel pad with a new one.**
- **When installing the wheel pad, take care that the wirings do not interfere with other parts and are not pinched between other parts.**



- (a) Connect the airbag connector.
- (b) Install the pad after confirming that the circumference groove of the torx screw is caught on the screw case.
- (c) Using a torx socket wrench, torque the 2 screws.

Torque: 8.8 N·m (90 kgf·cm, 78 in·lbf)

- (d) Install the steering wheel lower No.2 and No.3 covers.

15. CHECK STEERING WHEEL CENTER POINT