


DTC	C1254 / 54	Pressure Switch Circuit
-----	------------	-------------------------

CIRCUIT DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
C1254 / 54	Either of the following (1) or (2) is detected: (1) After turning the ignition switch ON, short or open circuit in pressure switch (PL) continued for more than 1 sec. (2) After turning the ignition switch ON, open circuit in pressure switch (PH) continued for more than 1 sec.	<ul style="list-style-type: none"> Pressure switch (PH or PL) Pressure switch circuit


WIRING DIAGRAM



F03926

INSPECTION PROCEDURE

1 Check pressure switch (PL) operation.



PREPARATION:

- Remove ABS & TRC & VSC ECU with connectors still connected.
- Turn the Ignition switch OFF, and depress the brake pedal 40 times or more.
- Disconnect the connector from the hydraulic brake booster.

CHECK:

While checking the resistance between terminals PL and PLG of hydraulic brake booster, depress the brake pedal with force of more than 294 N (30 kgf, 66 lbf) and turn the Ignition switch ON, then check the voltage between terminals PMC and GND of ECU when the resistance changes from 5.7 kΩ to 1.0 kΩ.

OK:

2.3 – 3.7 V

PREPARATION:

- Turn the Ignition switch OFF and disconnect the connector from the hydraulic brake booster.
- Turn the Ignition switch ON.

CHECK:

While checking the resistance between terminals PL and PLG of hydraulic brake booster, depress the brake pedal changing the force in the range of 197 N (20 kgf, 44 lbf) to 294 N (30 kgf, 66 lbf) and turn the Ignition switch ON, then check the voltage between terminals PMC and GND of ECU when resistance changes from 1.0 kΩ to 5.7 kΩ.

OK:

2.2 – 3.3 V

HINT:

After inspection, clear the DTC (See page DI-210).

OK

Go to step 3.

NG

- 2 Check for short circuit in harness and connector between master cylinder pressure sensor and ABS & TRC & VSC ECU (See page DI-29).


NG

Repair or replace harness or connector.

OK

Replace hydraulic brake booster.

- 3 Check pressure switch (PH) operation.

**PREPARATION:**

- (a) Remove ABS & TRC & VSC ECU with connectors still connected.
 (b) Turn the Ignition switch OFF, and depress the brake pedal 40 times or more.

CHECK:

While checking the voltage between terminals PH and GND of ECU, depress the brake pedal with force of more than 294 N (30 kgf, 66 lbf) and turn the Ignition switch ON, then check the voltage between terminals PMC and GND of ECU when voltage changes from 6V to 0V.

OK:

3.0 - 4.7 V

PREPARATION:

- (a) Turn the Ignition switch OFF and disconnect the connector from the hydraulic brake booster.
 (b) Turn the Ignition switch ON.

CHECK:

While checking the resistance between terminals PH and PHG, depress the brake pedal changing the force in the range of 197 N (20 kgf, 44 lbf) to 294 N (30 kgf, 66 lbf) and check the resistance between terminals PMC and GND of ECU when resistance changes from 0 kΩ to 1 kΩ.

OK:

2.9 - 4.3 V

HINT:

After inspection, clear the DTC (See page DI-210).

OK

Go to step 5.

NG

4 Check for short circuit in harness and connector between master cylinder pressure sensor and ABS & TRC & VSC ECU (See page IN-29).

NG

Repair or replace harness or connector.

OK

Replace hydraulic brake booster.

5 Check for open and short circuit in harness and connector between pressure switch and ABS & TRC & VSC ECU (See page IN-29).

NG

Repair or replace harness or connector.

OK

Check and replace ABS & TRC & VSC ECU.