

<b>DTC</b>	<b>P1335</b>	<b>Crankshaft Position Sensor Circuit Malfunction (During engine running)</b>
------------	--------------	---

## CIRCUIT DESCRIPTION

Refer to DTC P0335 on [page DI-144](#).

DTC No.	DTC Detecting Condition	Trouble Area
P1335	No crankshaft position sensor signal to engine ECU with engine speed 1,000 rpm or more	<ul style="list-style-type: none"><li>• Open or short in crankshaft position sensor circuit</li><li>• Crankshaft position sensor</li><li>• Crankshaft timing pulley</li><li>• Engine ECU</li></ul>

## WIRING DIAGRAM

Refer to DTC P0335 on [page DI-144](#).

## INSPECTION PROCEDURE

HINT:

Refer to DTC P0335 on [page DI-144](#).