



INSTALLATION

1. CHECK TORQUE CONVERTER INSTALLATION

Using calipers and a straight edge, measure the distance from the installed surface of the transmission housing to the installed surface of the torque converter.

Correct distance: More than 17.1 mm (0.673 in.)

If the distance is less than the standard, check for an improper installation.

2. INSTALL TRANSMISSION

Installation is in the reverse order of removal

([See page AT-26](#)).

HINT:

After installation, check and inspect items as follows.

- Adjust the shift lever position ([See page DI-278](#)).
- Fill ATF and check fluid level ([See page DI-278](#)).
- Do the road test ([See page DI-278](#)).