

Transmission Control Switch Circuit

CIRCUIT DESCRIPTION

When the shift lever is in the 4 range (with transmission control switch for D and 4 pressed), "4" in the shift position indicator light will come on and when the shift lever is in the D range (with transmission control switch for D and 4 released), "D" in the shift position indicator light will come on.

When the shift lever is in the L range (with transmission control switch for 2 and L pressed), "L" in the shift position indicator light will come on and when the shift lever is in the 2 range (with transmission control switch for 2 and L released), "2" in the shift position indicator light will come on.

WIRING DIAGRAM

See page DI-333.

INSPECTION PROCEDURE

1 Check operation of transmission control switch.

PREPARATION:

Turn ignition switch ON.

CHECK:

Check shift indicator light when the shift lever is in the each range.

OK:


Shift lever range	Specified condition
D	"D" indicator light comes on
Except D	"D" indicator light goes off
4	"4" indicator light comes on
Except 4	"4" indicator light goes off
2	"2" indicator light comes on
Except 2	"2" indicator light goes off
L	"L" indicator light comes on
Except L	"L" indicator light goes off

OK

Go to step 4.

NG

2 Check voltage between each terminals of D, 4, 2 and L of Engine & ECT ECU and body ground.



PREPARATION:

Remove the Engine & ECT ECU with connector S still connected.

CHECK:

- (a) Turn ignition switch ON.
- (b) Check voltage between each terminals of D, 4, 2 and L of Engine & ECT ECU and body ground.

OK:

Tester connection	Shift lever range	Specified condition
D - Body ground	D or 4	9 - 14 V
	Except D and 4	Below 1.5 V
4 - Body ground	4	9 - 14 V
	Except 4	Below 1.5 V
2 - Body ground	2 or L	9 - 14 V
	Except 2 and L	Below 1.5 V
L - Body ground	L	9 - 14 V
	Except L	Below 1.5 V

OK

Proceed to next circuit inspection shown in problem symptoms table (See page DI-294).

NG

3 Check harness and connector between battery and Engine & ECT ECU, Engine & ECT ECU and shift indicator light (See page N-30).


NG

Repair or replace harness or connector.

OK

Check and replace Engine & ECT ECU (See page N-30).

4 Check transmission control switch.



CHECK:

- (a) Disconnect the shift lock control unit assembly.
- (b) Check continuity between each terminal of shift lock control unit connector.

OK:

Shift position	Tester connection	Specified value
D	2 – 10 (AT4 – NSSD)	No continuity
4		Continuity
2	5 – 9 (ATL – NSSL)	No continuity
L		Continuity

NG

Replace shift lock control unit assembly.

OK

Check and replace combination meter (See combination meter troubleshooting section on [page IN-30](#)).