

INSTALLATION

Installation is in the reverse order of removal (See page SA-44).

AFTER INSTALLATION, CHECK ABS SPEED SENSOR SIGNAL (See page DI-210) AND REAR WHEEL ALIGNMENT (See page SA-7)