

PROBLEM SYMPTOMS TABLE

• POWER WINDOW CONTROL SYSTEM

Symptom	Suspect Area	See page
Power window does not operate.	1. Power window switch circuit 2. Power window motor circuit 3. Rear right door ECU	DI-799 BE-184
Auto up (or down) function does not operate.	1. Power window switch circuit 2. Rear right door ECU	DI-799
Jam protection function and auto up (or down) function does not operate.	1. Jam protection limit switch circuit 2. Jam protection pulse switch circuit 3. Rear right door ECU	BE-184 BE-184

• OTHERS

Symptom	Suspect Area	See page
Parts of the door does not function.	1. Power source circuit 2. Rear right door ECU	DI-789