

DISASSEMBLY

1. REMOVE HEADREST SUPPORTS

2. REMOVE SHOULDER BELT GUIDE

Remove the 6 screws and 3 shoulder belt guides.

3. REMOVE CENTER ARMREST

Remove the 2 nuts and center armrest from the seatback assembly.

4. REMOVE SEAT CUSHION COVER

Remove the hog rings and seat cushion cover from the seat cushion pad.

5. REMOVE SEATBACK COVER

Remove the hog rings and seatback cover from the seatback pad.