

TROUBLESHOOTING

PROBLEM SYMPTOMS TABLE

PR02W-03

| Symptom | Suspect Area | See page |
|-----------|---|--|
| Noise | 1. Center bearing (Worn) 2. Flexible rubber coupling (Worn) 3. Spider bearing (Worn or stuck) | PR-6 PR-6 PR-7 |
| Vibration | 1. Transmission extension housing rear bushing (Worn) 2. Flexible coupling (Worn) 3. Propeller shaft (Runout) 4. Propeller shaft (Imbalance) | – PR-6 PR-7 – |