

## 7. Navigation screen not stabilized (Synchronous error).

### INSPECTION PROCEDURE

1	Check the navigation ECU.
---	---------------------------

**CHECK:**

Check terminals +B.

**OK:****+B: 10 – 14 V****CHECK:**

Check terminal ACC when turn ignition switch ACC or ON position.

**OK:****ACC: 10 – 14 V****CHECK:**

Check terminal SYNC, VR or VG.

**OK:****SYNC, VR, VG: See "Navigation ECU" of "TERMINAL OF ECU"****NG****Replace the wire harness when all terminals are faulty. Replace the wire harness when the SYNC terminal is faulty.****OK****Replace the multi display.**