



ADJUSTMENT

1. ADJUST REAR DOOR IN FORWARD/REARWARD AND VERTICAL DIRECTIONS

- Remove the front and rear door scuff plates.
- Remove the center pillar lower garnish.
- Remove the 2 bolts and front seat belt retractor.

- Loosen the body side nuts to adjust.

Torque: 32.5 N·m (331 kgf·cm, 24 ft·lbf)

- Install the front seat retractor with the bolts.

Torque:

Upper bolt: 4.9 N·m (50 kgf·cm, 43 in·lbf)

Lower bolt: 42 N·m (430 kgf·cm, 31 ft·lbf)

- Install the center pillar lower garnish.
- Install the front and rear scuff plates.

2. ADJUST REAR DOOR IN LEFT/RIGHT VERTICAL DIRECTIONS

Using a wrench, loosen the door side hinge bolts.

Torque: 32.5 N·m (331 kgf·cm, 24 ft·lbf)

3. ADJUST REAR DOOR LOCK STRIKER

(See page [BO-15](#))