



Power source circuit

This circuit provides power to operate the rear right door ECU.



Rear Right (RHD)



105628

INSPECTION PROCEDURE

1	Check MPXB, GAUGE and DOOR(RR) fuse.
----------	---

CHECK:

Check continuity of MPXB, GAUGE and DOOR(RR) fuse.

OK:

Continuity

NG

Replace the failure fuse.

OK

2	Check voltage between terminals BDR, CPUB, SIG and GND of rear right door ECU connector.
----------	---

PREPARATION:

Turn ignition switch ON.

CHECK:

Measure voltage between terminals SIG, and GND.

OK:

Voltage: 10 – 14V

PREPARATION:

(a) Turn ignition switch OFF.

(b) Disconnect the rear right door ECU connector.

CHECK:

Measure voltage between terminals BDR, CPUB and GND.

OK:

Voltage: 10 – 14V

OK

Proceed to next circuit inspection shown on problem symptoms table (See page DI-788).

NG

3	Check wireharness and connector between ECU and body ground.
---	--

NG

Repair or replace wireharness or connector.

OK

Check and repair wireharness and connector between ECU and battery.