

Fuel gauge

INSPECTION PROCEDURE

HINT:  
If there is not the LEXUS hand-held tester, begin with STEP 2.

1 Perform active test.

**PREPARATION:**  
(a) Connect the LEXUS hand-held tester to the DLC3.  
(b) Turn ignition switch ON and LEXUS hand-held tester main switch ON.  
(c) Select the ACTIVE TEST mode on the LEXUS hand-held tester.  
**CHECK:**  
Check that the probe moves as LEXUS hand-held tester directs in each range.  
**OK:**  
The probe operates normally.

OK

Proceed to next circuit inspection shown on problem symptoms table. (See page DI-584).

NG

2 Check fuel receiver gauge (See page BE-105).

NG

Replace fuel receiver gauge.

OK

3 Check fuel sender gauge (See page BE-105).

NG

Replace fuel sender gauge.

OK

4 Check circuit plate (See page BE-105).

NG

Replace circuit plate.

OK

Check and replace combination meter (See page BE-91).