


| | | |
|------------|-----------------|--|
| DTC | P1780/97 | Park/Neutral Position Switch Circuit (Neutral Start Switch) |
|------------|-----------------|--|

CIRCUIT DESCRIPTION


The neutral start switch detects the shift lever range and sends signals to the Engine & ECT ECU. The Engine & ECT ECU receives signals (NSW, R, 2 and L) from the neutral start switch. When the signal is not sent to the Engine & ECT ECU from the neutral start switch, the Engine & ECT ECU judges that the shift lever is in D range.

| DTC No. | DTC Detection Condition | Trouble Area |
|----------|--|---|
| P1780/97 | 2 or more switches are ON simultaneously for R, N, 2 and L ranges. (2-trip detection logic) | <ul style="list-style-type: none"> • Short in neutral start switch circuit • Neutral start switch • Engine & ECT ECU |
| | When driving under conditions (a) and (b) for 30 seconds or more, the neutral start switch is ON (N position). (2-trip detection logic) (a) Vehicle speed: 70 km/h (44 mph) or more (b) Engine speed: 1,500 ~ 2,500 rpm | |

WIRING DIAGRAM



D02217



D02363

INSPECTION PROCEDURE

HINT:

In case of using the hand-held tester, start the inspection from step 1 and in case of not using the hand-held tester, start from step 2.

1 Read PNP, REVERSE, DRIVE, 4TH, 3RD, 2ND and LOW signals.

PREPARATION:

- (a) Remove the DLC3 cover.
- (b) Connect a hand-held tester to the DLC3.
- (c) Turn the ignition switch ON and hand-held tester main switch ON.

CHECK:

Shift lever into the P, R, N, 4, 3, 2 and L ranges, and read the PNP, REVERSE, 2ND and LOW signals on the hand-held tester.

OK:

| Shift range | Signal |
|-------------|--------------------|
| P/N | PNP [OFF] → ON |
| R | REVERSE [OFF] → ON |
| D | DRIVE [OFF] → ON |
| 4 | 4TH [OFF] → ON |
| 3 | 3RD : OFF → ON |
| 2 | 2ND : OFF → ON |
| L | LOW : OFF → ON |


OK

Check and replace the Engine & ECT ECU (See page N-29).

NG

Go to step 3.

2 Measure voltage between each terminals of P, R, N, D, 4, 3, 2, and L of Engine & ECT ECU and body ground.



PREPARATION:

Turn the Ignition switch ON.

CHECK:

Measure voltage between each terminals P, R, N, D, 4, 3, 2 and L of Engine ECT ECU and body ground when the shift lever is shifted to the following positions.

OK:

| Tester connection | Condition | specified condition |
|-------------------|--|---------------------------|
| P – Body ground | Shift lever range P | Battery positive voltage |
| R – Body ground | Shift lever range R | Battery positive voltage* |
| N – Body ground | Shift lever range N | Battery positive voltage |
| D – Body ground | Shift lever range D Transmission control SW (for D and 4) OFF | Battery positive voltage |
| 4 – Body ground | Shift lever range 4 Transmission control SW (for D and 4) ON | Battery positive voltage |
| 3 – Body ground | Shift lever range 3 | Battery positive voltage |
| 2 – Body ground | Shift lever range 2 Transmission control SW (for 2 and L) OFF | Battery positive voltage |
| L – Body ground | Shift lever range L Transmission control SW (for 2 and L) ON | Battery positive voltage |

HINT:


*: The voltage will drop slightly due to lighting up of the back up light.

OK

Check and replace the Engine & ECT ECU
(See page N-29).

NG

3 Check neutral start switch.



PREPARATION:

- (a) Jack up the vehicle.
- (b) Remove the neutral start switch connector.

CHECK:

Check continuity between each terminal shown below when the shift lever is moved to each range.

OK:

| Shift Range | Terminal No. to continuity | Terminal No. to continuity |
|-------------|----------------------------|----------------------------|
| P | 4 - 7 | 5 - 6 |
| R | 4 - 8 | - |
| N | 4 - 10 | 5 - 6 |
| D, 4 | 4 - 9 | - |
| 3 | 2 - 4 | - |
| 2, L | 3 - 4 | - |

NG

Replace the neutral start switch.

OK

Repair or replace harness and connector between battery and neutral start switch, neutral start switch and Engine & ECT ECU (See page IN-29).