

14. Map is displayed in white or blue screen. (Switches and vehicle position mark is displayed)**INSPECTION PROCEDURE**

1	Set the map scale to the max.
----------	--------------------------------------

OK

Normal.

HINT:

Correct the current position and check it again.

NG

2	Wipe the disc with a soft cloth, insert it again, and turn the ignition switch ON from OFF.
----------	--

NG

Replace the disc.

OK

Normal.

HINT:

If the trouble still occurs, replace the navigation ECU.