

PROBLEM SYMPTOMS TABLE
DOUBLE LOCKING SYSTEM

Symptom	Suspect Area	See page
Double locking system does not operate	1. Double locking switch circuit 2. Double locking motor circuit 3. Double locking system 4. Rear left door ECU	DI-708