



REMOVAL

GS 430:

REMOVE DRIVE BELT

Loosen the drive belt tension by turning the drive belt tensioner counterclockwise and remove the drive belt.