


2. Display Portion



230LX58

Item	Display Contents	Outline
Average Vehicle Speed After Starting	AVG. 52.5 km/h <small>230LX59</small>	<ul style="list-style-type: none"> Displays the value that has been calculated by the meter ECU, which is based on the elapsed time and driven distance after the ignition switch has been turned ON or the RESET button has been pressed 0.8 seconds or longer. The display updates every 10 seconds.
Average Fuel Consumption After Refueling	AVG. 9.6 L/100km <small>230LX60</small>	<ul style="list-style-type: none"> Displays the value that has been calculated by the meter ECU, which is based on the driven distance after refueling and the fuel consumption volume (fuel injection signal from No. 1 injector). The meter ECU determines that the vehicle has been refueled in accordance with the signal from the fuel sender gauge. The display updates every 10 seconds.
Instant Fuel Consumption	9.2 L/100km <small>230LX61</small>	<ul style="list-style-type: none"> Displays the value that has been calculated by the meter ECU, which is based on the driven distance and the fuel consumption volume (fuel injection signal from No. 1 injector), provided that the ignition switch is turned ON. The display updates every 2 seconds.
Driven Distance After Starting	DISTANCE 270.0 km <small>230LX62</small>	<ul style="list-style-type: none"> Displays the driven distance that is output by the meter ECU after the ignition switch has been turned ON or the RESET button has been pressed 0.8 seconds or longer. The display updates every kilometer.
Drivable Distance	RANGE 536 km <small>230LX63</small>	<ul style="list-style-type: none"> Displays the value that has been calculated by the meter ECU, which is based on the fuel consumption data that the meter ECU continuously monitors and stores in its memory and the residual fuel volume data, provided that the ignition switch is turned ON. The display updates every kilometer.