

REMOVAL


1. REMOVE INTAKE AIR RESONATOR

2. REMOVE NO.3 TIMING BELT COVER

Using a 5 mm hexagon wrench, remove the 4 bolts, oil filler cap, No.3 timing belt cover and gasket.

3. DISCONNECT THROTTLE BODY FROM INTAKE AIR CONNECTOR WITHOUT DISCONNECTING WATER BYPASS HOSES

- (a) Disconnect the accelerator cable.
- (b) Disconnect these connectors and clamp:
 - Throttle position sensor connector
 - Throttle control motor connector
 - Accelerator pedal position sensor connector
 - Engine wire clamp from clamp bracket of throttle body




- (c) Remove the 2 bolts and nut holding the throttle body to the intake air connector.

Torque: 21 N·m (210 kgf·cm, 15 ft·lbf)


- (d) Remove the 4 nuts and the throttle body bracket.

Torque: 21 N·m (210 kgf·cm, 15 ft·lbf)



- (e) Disconnect the water bypass hose from the hose clamp on the oil filter bracket.


- (f) Slightly slide the throttle body away from the intake air connector.



4. REMOVE THROTTLE BODY GASKET


Remove the 3 bolts and throttle body gasket.

Torque: 21 N·m (210 kgf·cm, 15 ft·lbf)




5. REMOVE IGNITION COILS AND HIGH - TENSION CORDS SET ASSEMBLY

- (a) Disconnect the 3 connectors from the ignition coils.
- (b) Remove the 2 bolts, and disconnect the clamps from the engine wire.



- (c) Remove the 3 bolts, the ignition coils and high - tension cord set assembly.

Torque: 8.0 N·m (80 kgf·cm, 71 in.·lbf)



6. REMOVE IGNITION COILS FROM HIGH - TENSION CORD SET