



DISASSEMBLY

REMOVE SUSPENSION SUPPORT AND COIL SPRING

- (a) Using SST, compress the coil spring.

SST 09727-30021

NOTICE:

Do not use an impact wrench. It will damage the SST.

- (b) Remove the piston rod lock nut.
(c) Remove the suspension support sub-assembly, spring bumper and coil spring.