


INSPECTION

1. Ex. Australia Models:
INSPECT FRONT FOG LIGHT SWITCH CONTINUITY

Switch position	Tester connection	Specified condition
OFF	-	No continuity
ON	11 - 12	Continuity

If continuity is not as specified, replace the switch.




2. Ex. Australia Models:
INSPECT FRONT FOG LIGHT SWITCH CIRCUIT
Connector disconnected:
(See page DI-668)

Disconnect the connector from the switch and inspect the connector on the wire harness side, as shown.

Tester connection	Condition	Specified condition
11 - Ground	Light control switch TAIL or HEAD and dimmer switch LOW or HI	Continuity

If circuit is not as specified, inspect the wire harness.




3. Ex. Australia Models:
INSPECT FRONT FOG LIGHT SWITCH CIRCUIT
Connector connected:

Connect the wire harness side connector to the light control and dimmer switch and inspect the connector from the back side, as shown.

Tester connection	Condition	Specified condition
11 – Ground	Light control switch HEAD and headlight dimmer switch LO and fog light switch ON	No voltage
11 – Ground	Light control switch HEAD and headlight dimmer switch HI or FLASH and fog light switch ON	Battery positive voltage


If circuit is not as specified, inspect the wire harness.



4. Australia Models:
INSPECT FRONT FOG LIGHT SWITCH CONTINUITY

Switch position	Tester connection	Specified condition
OFF	–	No continuity
ON	12 – 16	Continuity

If continuity is not as specified, replace the switch.




5. Australia Models:
INSPECT FRONT FOG LIGHT SWITCH CIRCUIT
Connector disconnected:
(See page DI-668)

Disconnect the connector from the switch and inspect the connector on the wire harness side, as shown.

Tester connection	Condition	Specified condition
16 – Ground	Light control switch TAIL or HEAD and dimmer switch LOW or HI	Continuity

If circuit is not as specified, inspect the wire harness.




6. Australia Models:
INSPECT FRONT FOG LIGHT SWITCH CIRCUIT
Connector connected:

Connect the wire harness side connector to the light control and dimmer switch and inspect the connector from the back side, as shown.

Tester connection	Condition	Specified condition
16 – Ground	Light control switch HEAD and headlight dimmer switch LO and fog light switch ON	No voltage
16 – Ground	Light control switch HEAD and headlight dimmer switch HI or FLASH and fog light switch ON	Battery voltage


If circuit is not as specified, inspect the wire harness.



**7. Europe Models:
INSPECT REAR FOG LIGHT SWITCH CONTINUITY**

Switch position	Tester connection	Specified condition
OFF	–	No continuity
ON	3 – 4	Continuity
Illumination circuit	1 – 2	Continuity

If continuity is not as specified, replace the switch.




**8. Europe Models:
INSPECT REAR FOG LIGHT SWITCH CIRCUIT**

Disconnect the switch connector and inspect the connection on the wire harness side, as shown.

Tester connection	Condition	Specified condition
*1 – Ground 4 – Ground	Light control switch OFF	Continuity
*1 – Ground 4 – Ground	Light control switch TAIL or HEAD	Continuity

If circuit is not as specified, inspect the circuits connected to other parts.




9. INSPECT FRONT FOG LIGHT RELAY CONTINUITY

Condition	Tester connection	Specified condition
Constant	1 – 2	Continuity
Apply B+ between terminals 1 and 2.	3 – 5	Continuity

If continuity is not as specified, replace the relay.

10. INSPECT FRONT FOG LIGHT RELAY CIRCUIT
(See page BE-21)



11. Europe Models:
INSPECT REAR FOG LIGHT RELAY CONTINUITY

Condition	Tester connection	Specified condition
Constant	1 - 2	Continuity
Apply B+ between terminals 1 and 2.	3 - 5	Continuity

If continuity is not as specified, replace the relay.

12. Europe Models:
INSPECT REAR FOG LIGHT RELAY CIRCUIT
(See page BE-21)