

DTC	B1271/71	Combination meter ECU communication stop
-----	----------	--

CIRCUIT DESCRIPTION

This DTC is output when communication stops between combination meter ECU and body No.1 ECU.

DTC No.	DTC Detecting Condition	Trouble Area
B1271/71	No communication from Combination meter ECU more than 10 seconds.	<ul style="list-style-type: none">Combination meter ECUWireharness

WIRING DIAGRAM

See page DI-753

INSPECTION PROCEDURE

1	Check combination meter ECU.
---	------------------------------


CHECK:

Start the engine and check that the speed meter and tachometer operate normally.


HINT:

With this inspection, the combination meter ECU CPU can be diagnosed if it works normally or not.

NG	Replace the combination meter ECU.
----	------------------------------------



2 Check wireharness



PREPARATION:

Disconnect connector "B6" of body No.2 ECU, "C12" of combination meter ECU, "C8" of airbag sensor assembly.

CHECK:

- Check continuity between terminals MPX1 of body No.2 ECU and MPX- of combination meter ECU.
- Check continuity between terminals MPX2 of airbag sensor assembly and MPX+ of combination meter ECU.

OK:

Continuity exists in wireharness of both (a) and (b), or either (a) or (b).

HINT:

If there is OPEN in wireharness of either (a), or (b), please repair it.

NG

Repair or replace wireharness.

OK

Replace the combination meter ECU.