


DTC	C1257 / 57	Power Supply Drive Circuit
-----	------------	----------------------------

## CIRCUIT DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
C1257 / 57	After the ignition switch has been turned ON, open or short circuit in circuit of power supply drive system inside ECU continues for more than 1.5 secs.	<ul style="list-style-type: none"> <li>• Battery</li> <li>• Power source circuit</li> <li>• ABS &amp; TRC &amp; VSC ECU</li> </ul>

## WIRING DIAGRAM



F03932

## INSPECTION PROCEDURE

### 1 Check battery voltage.

**OK:**

Voltage: 10 – 14 V

**NG**

Check and repair the charging system.

**OK**

### 2 Check voltage of the ECU IG power source.

**In case of using the hand-held tester.****PREPARATION:**


- (a) Connect the hand-held tester to the DLC3.
- (b) Turn the ignition switch ON and push the hand-held tester main switch ON.
- (c) Select the DATALIST mode on the hand-held tester.

**CHECK:**

Check the voltage condition output from the ECU displayed on the hand-held tester.

**OK:**

"Normal" is displayed.

**In case of not using the hand-held tester.****PREPARATION:**

Remove ABS &amp; TRC &amp; VSC ECU with connectors still connected.

**CHECK:**

- (a) Turn the ignition switch ON.
- (b) Measure voltage between terminals IG1 and GND of ABS & TRC & VSC ECU connector.

**OK:**


Voltage: 10 – 14 V

**OK**

Ignition switch OFF, check and replace ABS &amp; TRC &amp; VSC ECU.

**NG**

### 3 Check continuity between terminal GND of ABS & TRC & VSC ECU connector and body ground.



#### CHECK:

Measure resistance between terminal GND of ABS & TRC & VSC ECU connector and body ground.

#### OK:


Resistance: 1 Ω or less

NG

Repair or replace harness or connector.

OK

### 4 Check ECU-IG fuse.



#### PREPARATION:

Remove ECU-IG fuse from the driver's side J/B.

#### CHECK:

Check continuity of ECU-IG fuse.

#### OK:

Continuity

NG

Check for short in all the harness and components connected to ECU-IG fuse (See attached wiring diagram).

OK

Check for open circuit in harness and connector between ABS & TRC & VSC ECU and battery (See page N-29).