

PROBLEM SYMPTOMS TABLE

DOUBLE LOCKING SYSTEM

Symptom	Suspect Area	See page
Double locking system does not operate	1. Double locking switch circuit 2. Double locking motor circuit 3. Double locking system 4. Each door ECU 5. Body ECU No. 1	DI-660 DI-690 DI-708 DI-728 DI-658 DI-688 DI-710 DI-730 BE-18 IN-30 IN-30

OTHERS

Symptom	Suspect Area	See page
Mirror retract system does not operate	1. Electrical retract switch circuit 2. Retract motor circuit 3. Body ECU No. 1	DI-605 DI-656 DI-686 IN-30
DTC is not output, or is output when should not be.	1. Diagnosis circuit 2. Body ECU No. 1	DI-617 IN-30
Unlock cannot be operated when impact sensing	1. Supplemental restraint system 2. Body No.1 ECU	DI-605 IN-30