

HYDRAULIC BRAKE BOOSTER ON-VEHICLE INSPECTION

BR0K7-02

1. HYDRAULIC BRAKE BOOSTER OPERATION INSPECTION

- (a) Inspect the battery voltage.
Battery voltage: 10 – 14 V
- (b) Turn the ignition switch OFF, depress the brake pedal more than 40 times.
- (c) Install LSPV gauge (SST) and brake pedal effort gauge, bleed air.
SST 09709-29018
- (d) When booster does not operate.
Depress the brake pedal and check fluid pressure.

At 245 N (25 kgf, 55 lbf):

Front brake pressure	Rear brake pressure
1,470 kPa (15 kgf/cm ² , 213 psi) or more	0 kPa (0 kgf/cm ² , 0 psi)

At 343 N (35 kgf, 77 lbf):

Front brake pressure	Rear brake pressure
2,059 kPa (21 kgf/cm ² , 299 psi) or more	0 kPa (0 kgf/cm ² , 0 psi)

- (e) When booster operate.
 - (1) Turn the ignition switch ON and wait until the pump motor has stopped.
 - (2) Depress the brake pedal and check fluid pressure.

At 49 N (5 kgf, 11 lbf):

Front brake pressure	Rear brake pressure
1,255 – 1,814 kPa (12.8 – 18.5 kgf/cm ² , 182 – 263 psi)	1,285 – 2,148 kPa (13.1 – 21.9 kgf/cm ² , 186 – 311 psi)

At 98 N (10 kgf, 22 lbf):

Front brake pressure	Rear brake pressure
2,765 – 4,021 kPa (28.2 – 41.0 kgf/cm ² , 401 – 583 psi)	3,128 – 4,482 kPa (31.9 – 45.7 kgf/cm ² , 454 – 650 psi)

At 147 N (15 kgf, 33 lbf):

Front brake pressure	Rear brake pressure
4,266 – 6,139 kPa (43.5 – 62.6 kgf/cm ² , 619 – 890 psi)	4,599 – 6,541 kPa (46.9 – 66.7 kgf/cm ² , 667 – 949 psi)

At 196 N (20 kgf, 44 lbf):

Front brake pressure	Rear brake pressure
5,982 – 8,100 kPa (61.0 – 82.6 kgf/cm ² , 868 – 1,175 psi)	6,296 – 8,414 kPa (64.2 – 85.8 kgf/cm ² , 913 – 1,220 psi)


2. IN CASE OF USING HAND-HELD TESTER

- (a) Inspect the battery voltage.

Battery voltage: 10 – 14 V

- (b) Turn the ignition switch OFF, depress the brake pedal more than 40 times.
- (c) Check that the brake pedal becomes heavy to depress. If the pedal does not become to be heavy to depress, check and replace the brake line and hydraulic brake booster.
- (d) Turn the ignition switch ON, check the pump motor operation noise.

If the pump motor does not operate, check and replace the wire harness and pump motor.



- (e) Connect the hand-held tester.
- (1) Connect the hand-held tester to the DLC3.
 - (2) Turn the ignition switch ON.
 - (3) Select the "ACTIVE TEST" mode on the hand-held tester.

HINT:

- Please refer to the hand-held tester operator's manual for further details.
 - To protect the solenoids, hand-held tester turns OFF automatically 2 secs. after every solenoid has been turned ON.
- (f) Inspect the front TRC & VSC solenoid operation.
- (1) Select "SA1" and "SA2" on the hand-held tester.
 - (2) With "SA1" and "SA2" turned ON simultaneously with the hand-held tester, depress the brake pedal with stable force and check that the pedal cannot be depressed.

HINT:

To protect the solenoids, hand-held tester turns OFF automatically 2 secs. after has been turned ON.

If the pedal can be depressed, replace the hydraulic brake booster.

NOTICE:

When operating it continuously, set the interval of more than 20 seconds.

- (3) Once, release the brake pedal.

- (4) When the solenoids are OFF, after depressing the pedal again and check that the pedal can be depressed.

If the pedal cannot be depressed, replace the hydraulic brake booster.

- (g) Inspect the front ABS solenoid operation.
 - (1) Select "SFRH" and "SFLH" on the hand-held tester.
 - (2) With "SFRH" and "SFLH" turned ON simultaneously with the hand-held tester, depress the brake pedal with stable force and check that the pedal cannot be depressed.

HINT:

To protect the solenoids, hand-held tester turns OFF automatically 2 secs. after has been turned ON.

If the pedal can be depressed, replace the hydraulic brake booster.

- (3) When the solenoids are OFF, check that the pedal can be depressed.

If the pedal cannot be depressed, replace the hydraulic brake booster.

- (4) Once, release the brake pedal. After depressing and holding the pedal with stable force, turn the SFRH and SFRR solenoids ON simultaneously.

HINT:

To protect the solenoids, hand-held tester turns OFF automatically 2 secs. after has been turned ON.

- (5) When the solenoids are OFF, check that the pedal can be depressed.

If the pedal cannot be depressed, replace the hydraulic brake booster.

- (6) Once, release the brake pedal. After depressing the pedal with stable force, turn the SFLH and SFLR solenoids ON simultaneously.

HINT:

To protect the solenoids, hand-held tester turns OFF automatically 2 secs. after has been turned ON.

- (7) When the solenoids are OFF, check that the pedal can be depressed.

If the pedal cannot be depressed, replace the hydraulic brake booster.

- (h) Jack up and support the vehicle.
- (i) Release the parking brake pedal.
- (j) Inspect the rear TRC & VSC solenoid operation.
 - (1) Select the "SA3" and "STR" on the hand-held tester.

- (2) Turn the "SA3" and "STR" ON simultaneously with the hand-held tester, and check that the rear wheels by stopping them by hand.

HINT:

When rotating the wheel fast, the fail-safe function is activated and judgement cannot be made properly. So rotate the wheel as slowly as possible.

If the rear wheels rotate, replace the hydraulic brake booster.

- (3) Turn the "SA3" and "STR" OFF simultaneously, and check that the rear wheels by rotating them by hand.

HINT:

- To protect the solenoids, hand-held tester turns OFF automatically 2 secs. after has been turned ON.
- When rotating the wheel fast, the fail-safe function is activated and judgement cannot be made properly. So rotate the wheel as slowly as possible.

NOTICE:

When operating it continuously, set the interval of more than 20 secs.

If the rear wheels stop, replace the hydraulic brake booster.

- (k) Inspect the right rear ABS solenoid.
 - (1) Select the "SA3", "STR" and "SRRH", on the hand-held tester.
 - (2) Turn the "SA3", "STR" and "SRRH" ON simultaneously with the hand-held tester, and check that the right rear wheel by rotating them by hand.

HINT:

- To protect the solenoids, hand-held tester turns OFF automatically 2 secs. after has been turned ON.
- When rotating the wheel fast, the fail-safe function is activated and judgement cannot be made properly. So rotate the wheel as slowly as possible.
- When solenoid is OFF, the wheel might stop temporarily. However if the wheel rotates again, the function works normally.

If the rear wheels stop, replace the hydraulic brake booster.

- (3) Turn the "SA3", "STR" and "SRRH" OFF, and check that the rear wheel by stopping them by hand.

HINT:

- To protect the solenoids, hand-held tester turns OFF automatically 2 secs. after has been turned ON.
- When rotating the wheel fast, the fail-safe function is activated and judgement cannot be made properly. So rotate the wheel as slowly as possible.

If the rear wheels rotate, replace the hydraulic brake booster.

- (4) Depress the pedal with stable force, then turn the "SRRH" and "SRRR" ON simultaneously.
- (5) When the solenoids are ON, check that the right rear wheel by rotating them by hand.

- (l) Inspect the left rear ABS solenoid operation.
 - (1) Select the "SA3", "STR" and "SRLH" on the hand-held tester.
 - (2) Turn the "SA3", "STR" and "SRLH" ON with hand-held tester, and check that the left rear wheel by rotating them by hand.

HINT:

When rotating the wheel fast, the fail-safe function is activated and judgement cannot be made properly. So rotate the wheel as slowly as possible.

If the rear wheels stop, replace the hydraulic brake booster.

- (3) Turn the "SA3", "STR" and "SRLH" OFF and check that the rear wheels by rotating them by hand.

HINT:

- To protect the solenoids, hand-held tester turns OFF automatically 2 secs. after has been turned ON.
- When rotating the wheel fast, the fail-safe function is activated and judgement cannot be made properly. So rotate the wheel as slowly as possible.
- When solenoid is OFF, the wheel might stop temporarily. However if the wheel rotates again, the function works normally.

If the rear wheels rotate, replace the hydraulic brake booster.

- (4) Depress the pedal with stable force, then turn the "SRLH" and "SRLR" ON simultaneously.

HINT:


To protect the solenoids, hand-held tester turns OFF automatically 2 secs. after has been turned ON.

- (5) When the solenoids are ON, check that the right rear wheel by rotating them by hand.

HINT:

When rotating the wheel fast, the fail-safe function is activated and judgement cannot be made properly. So rotate the wheel as slowly as possible.

- (m) Lower the vehicle.
- (n) Disconnect the hand-held tester.

**3. IN CASE OF USING ABS ACTUATOR CHECKER**

- (a) Inspect the battery voltage.
Battery voltage: 10 – 14 V
- (b) Disconnect the 2 connectors from hydraulic brake booster.


- (c) Connect the actuator checker (SST) to the hydraulic brake booster side wire harness via the sub-wire harness (SST), as shown in the chart below.

SST 09990-00150, 09990-00480

HINT:

Connect the connector with the label of "FRONT" attached to the connector of actuator checker.


- (d) Connect the red cable of the checker to the battery positive (+) terminal and the black cable to the negative (-) terminal.



F02821

- (e) Place "SHEET G" (SST) of "FRONT" on actuator checker.
SST 09990-00240
- (f) Turn the ignition switch OFF, depress the brake pedal more than 40 times.
- (g) Check that the brake pedal becomes heavy to depress. If the pedal does not become to be heavy to depress, check and replace the brake line and hydraulic brake booster.
- (h) Turn the ignition switch ON, check the pump motor operation noise.

If the pump motor does not operate, check and replace the wire harness and pump motor.



- (i) Inspect the front TRC & VSC solenoid operation.
- (1) Push in and hold the "SA1" and "SA2" switches simultaneously, depress strongly and hold the brake pedal with stable force.

NOTICE:

Do not keep the "SA1" and "SA2" pushed down for more than 10 seconds. When operating it continuously, set the interval of more than 20 seconds.


- (2) Check that the brake pedal cannot be depressed. If the pedal can be depressed, replace the hydraulic brake booster.

- (3) Release the "SA1" switch and check that the pedal can be depressed.

If the pedal can be depressed, replace the hydraulic brake booster.

- (4) Release the "SA2" switch and check that the pedal can be depressed.

If the pedal can be depressed, replace the hydraulic brake booster.



- (j) Inspect the right front ABS solenoid operation.
- (1) Turn the selector switch to "RH" position.
 - (2) Push and hold in the MAIN push switch and "SA2" switch simultaneously depress and hold the brake pedal with stable force.

NOTICE:

Do not keep the MAIN push switch and "SA2" switch pushed down for more than 10 seconds. When operating it continuously, set the interval of more than 20 seconds.

- (3) Check that the brake pedal cannot be depressed. If the pedal can be depressed, replace the hydraulic brake booster.

- (4) Release the MAIN push switch and "SA2" switch simultaneously and check that the pedal can be depressed.

If the pedal cannot be depressed, replace the hydraulic brake booster.


- (5) Release the brake pedal.

- (6) Depress and hold the brake pedal with stable force, push and hold in MAIN push switch.

NOTICE:

Do not keep the MAIN push switch pushed down for more than 10 seconds. When operating it continuously, set the interval of more than 20 seconds.


- (7) Check that the brake pedal cannot be depressed. If the pedal can be depressed, replace the hydraulic brake booster.



- (8) Release the MAIN push switch and check that the pedal can be depressed.

If the pedal cannot be depressed, replace the hydraulic brake booster.

- (9) Release the brake pedal.



- (k) Inspect the left front ABS solenoid operation.

- (1) Turn the selector switch to "LH" position.
- (2) Push and hold in the MAIN push switch and "SA1" switch simultaneously, depress and hold the brake pedal with stable force.

NOTICE:

Do not keep the MAIN push switch and "SA1" switch pushed down for more than 10 seconds. When operating it continuously, set the interval of more than 20 seconds.


- (3) Check that the brake pedal cannot be depressed.

If the pedal can be depressed, replace the hydraulic brake booster.

- (4) Release the MAIN push switch and "SA1" switch simultaneously, and check that the pedal can be depressed.

If the pedal cannot be depressed, replace the hydraulic brake booster.

- (5) Release the brake pedal.



- (6) Depress and hold the brake pedal with stable force, push and hold in MAIN push switch.

NOTICE:

Do not keep the MAIN push switch pushed down for more than 10 seconds. When operating it continuously, set the interval of more than 20 seconds.

- (7) Check that the brake pedal cannot be depressed.

If the pedal can be depressed, replace the hydraulic brake booster.

- (8) Release the MAIN push switch and check that the pedal can be depressed.

If the pedal cannot be depressed, replace the hydraulic brake booster.


- (9) Release the brake pedal.

- (l) Turn the ignition switch OFF, then reconnect the connector of sub-wire harness from the one with label of "FRONT" to "REAR".

- (m) Place "SHEET G" of "REAR" on the actuator checker.

- (n) Jack up and support the vehicle.

- (o) Start the engine and run it at idle.



- (p) Inspect the rear TRC & VSC solenoid.
- (1) Release the parking brake pedal and shift the shift lever to "L" position.
 - (2) Push and hold the "SA3" switch and "STR" switch simultaneously.

NOTICE:

- **Do not keep the "STR" switch pushed down for more than 10 seconds.**
- **Do not keep the "SA3" switch pushed down for more than 5 seconds.**
- **When operating it continuously, set the interval of more than 20 seconds.**


- (3) Check that the rear wheels stop.

If the rear wheels rotate, replace the hydraulic brake booster.

- (4) Release the "SA3" switch and "STR" switch simultaneously.

- (5) Check that the rear wheels rotate.

If the rear wheels stop, replace the hydraulic brake booster.



- (q) Inspect the right rear ABS solenoid.
- (1) Turn the selector switch to "RH" position.
 - (2) Depress the brake pedal several times the release the pedal after the pump has begun to operate, and wait until the pump stops.
 - (3) Turn the ignition switch OFF.
 - (4) With push and hold in the MAIN push switch, depress the pedal with force of 196 N (20 kgf, 44 lbf) and hold it 6 times for 10 secs.

NOTICE:

When operating it continuously, set the interval of more than 20 seconds.


- (5) Check that pedal is not hard to depress.

If pedal is hard to depress, replace the hydraulic brake booster.

- (6) Start the engine and run it at idle.
- (7) Depress the brake pedal.
- (8) Release the parking brake pedal and shift the shift lever to "L" position.
- (9) Once, release the brake pedal. After depressing the brake pedal with stable force, then push and hold MAIN push switch.

- (10) Check that the right rear wheel rotate.

If the right rear wheels stop, replace the hydraulic brake booster.



- (r) Inspect the left rear ABS solenoid.
- (1) Turn the selector switch to "LH" position.
 - (2) Depress the brake pedal several times, release the pedal after the pump has begun to operate, and wait until the pump stops.
 - (3) Turn the ignition switch OFF.
 - (4) With push and hold in the MAIN push switch, depress the pedal with force of 196 N (20 kgf, 44 lbf) and hold it 6 times for 10 secs.

NOTICE:

When operating it continuously, set the interval of more than 20 seconds.

- (5) Check that pedal is not hard to depress.
If pedal is hard to depress, replace the hydraulic brake booster.
 - (6) Start the engine and run it at idle.
 - (7) Depress the brake pedal.
 - (8) Release the parking brake pedal and shift the shift lever to "L" position.
 - (9) Once, release the brake pedal. After depressing the brake pedal with stable force, then push and hold MAIN push switch.
 - (10) Check that the left rear wheel rotate.
If the left rear wheels stop, replace the hydraulic brake booster.
- (s) Stop the engine and lower the vehicle.
- (t) Remove the "SHEET G" (SST) and disconnect the actuator checker (SST) and sub-wire harness (SST) from the hydraulic brake booster.
- SST 09990-00150, 09990-00240, 09990-00480
- (u) Connect the 2 connectors to the actuator.
- (v) Clear the DTC (See page DI-210).