

THREE-WAY CATALYTIC CONVERTER (TWC) SYSTEM

ON-VEHICLE INSPECTION

EC05B-02

1. INSPECT EXHAUST PIPE ASSEMBLY

- (a) Check the connections for looseness or damage.
- (b) Check the clamps for weakness, cracks or damage.

2. INSPECT TWC

Check for dents or damage.

3. INSPECT TWC HEAT INSULATOR

- (a) Check the heat insulator for damage.
- (b) Check for adequate clearance between the TWC and heat insulator.