

## DISASSEMBLY

### 1. REMOVE DOOR INSIDE HANDLE BEZEL COVER


Using a screwdriver, remove the inside handle bezel cover.

HINT:

Tape the screwdriver tip before use.

### 2. REMOVE REAR DOOR COURTESY LIGHT

### 3. REMOVE ARMREST BASE PANEL



### 4. REMOVE DOOR TRIM

(a) Remove the 5 screws.

(b) Insert a screwdriver between the door panel and door trim to pry out.


**NOTICE:**

**Do not scratch the panel with the screwdriver.**

HINT:

Tape the screwdriver tip before use.

(c) Pull the trim upward to remove it, then disconnect the connectors.



(d) Remove the 2 cables from the door inside handle.

(e) Remove the 2 screws and door inside handle.

### 5. REMOVE ORNAMENT


### 6. REMOVE PANEL

### 7. REMOVE DOOR INSIDE HANDLE BEZEL

### 8. REMOVE REAR DOOR SPEAKER

### 9. REMOVE REAR DOOR FRAME GARNISH

### 10. REMOVE REAR DOOR ECU



### 11. REMOVE REAR DOOR INNER WEATHERSTRIP


Using a scraper, remove the inner weatherstrip.

HINT:


Tape the scraper tip before use.

### 12. REMOVE SERVICE HOLE COVER



### 13. REMOVE REAR DOOR GLASS RUN

**14. REMOVE DOOR GLASS**

Remove the 2 nuts and door glass.

**15. REMOVE DIVISION BAR**

- (a) Remove the 2 bolts and screw.
- (b) Remove the division bar.

**16. REMOVE REAR DOOR QUARTER WINDOW GLASS****17. REMOVE REAR DOOR QUARTER WINDOW GLASS WEATHERSTRIP****18. REMOVE WINDOW REGULATOR**

- (a) Disconnect the connector.
- (b) Remove the 4 bolts and window regulator.

**Torque: 8.0 N·m (82 kgf·cm, 71 in·lbf)**


**HINT:**

At the time of reassembly, please refer to the following item.  
Apply adhesive MP grease to window rollers.

**NOTICE:**

**At the time of reassembly, please refer to the following item.**

**Do not apply grease to the spring of the window regulator.**

**19. REMOVE DOOR LOCK**

- (a) Remove the child protection cover.
- (b) Disconnect the connector.
- (c) Remove the bolt.
- (d) Using a torx socket wrench, remove the 3 screws and door lock.

**Torque: 5.5 N·m (56 kgf·cm, 49 in.·lbf)**

**Torx wrench : T30 (Part No. 09042-00010 or locally manufactured tool)**

**Torque: 5.5 N·m (56 kgf·cm, 49 in.·lbf)**

**HINT:**

At the time of reassembly, please refer to the following item.

Apply adhesive to the 3 screws.

**Part No. 08833-00070, THREE BOND 1324 or equivalent.**

**HINT:**

At the time of reassembly, please refer to the following item.

Apply MP grease to the sliding and rotating parts of the door lock.

**20. REMOVE REAR DOOR OUTSIDE HANDLE**

- (a) Remove the 2 bolts.

**Torque: 5.5 N·m (56 kgf·cm, 49 in.·lbf)**

- (b) Remove the rear door outside handle.

**21. REMOVE REAR DOOR WEATHERSTRIP**