


<b>DTC</b>	<b>P0710/38</b>	<b>Transmission Fluid Temperature Sensor Malfunction (ATF Temperature Sensor)</b>
------------	-----------------	---

## CIRCUIT DESCRIPTION

The ATF temperature sensor converts fluid temperature into a resistance value which is input into the Engine & ECT ECU.


DTC No.	DTC Detecting Condition	Trouble Area
P0710/38	<p>Either (a) or (b) is detected for 0.5 sec. or more. (2-trip detection logic)</p> <p>(a) Temperature sensor resistance is less than 79 <math>\Omega</math></p> <p>(b) After the engine has been operating for 15 minutes or more, the resistance at the temp. sensor is more than 156 k<math>\Omega</math></p>	<ul style="list-style-type: none"> <li>• Open or short in ATF temperature sensor</li> <li>• ATF temperature sensor</li> <li>• Engine &amp; ECT ECU</li> </ul>

## WIRING DIAGRAM



## INSPECTION PROCEDURE

## 1 Check ATF temperature sensor.

**PREPARATION:**

- (a) Disconnect the solenoid wire connector.
- (b) Remove the oil pan.
- (c) Disconnect all solenoid valve connectors.
- (d) Remove transmission wire harness.

**CHECK:**

Measure resistance between terminals 1 and 7 of solenoid connector at 25°C (77°F) and 110°C (230°F).

**OK:**

**Resistance (Approx.):**

25°C (77°F): 3.5 kΩ

110°C (230°F): 231 ~ 263 Ω

NG

Replace the ATF temperature sensor (transmission wire).

OK

## 2 Check harness and connector between ATF temperature sensor and Engine &amp; ECT ECU (See page N-29).

NG

Repair or replace the harness or connector.

OK

Check and replace the Engine & ECT ECU (See page N-29).