

H PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
A 1	A/C Ambient Temp. Sensor	90980-11070	B 4	Blower Motor Controller	90980-11667
A 2	A/C Condenser Fan Motor	90980-10928	B 5	Body ECU No.1	90980-11877
A 3	A/C Magnetic Clutch and Lock Sensor	90980-11016	B 6	Body ECU No.2	
A 4	A/C Triple Pressure SW (A/C Dual and Single Pressure SW)	90980-10943	B 7	Buckle SW LH	90980-11399
A 5	ABS & TRC & VSC Actuator	90980-11151	B 8	Buckle SW RH	
A 6	ABS & TRC & VSC Actuator	90980-10895	B 9	Buckle SW LH and Seat Belt Warning Occupant Detection Sensor	90980-11599
A 7	ABS & TRC & VSC Actuator	90980-11413	B10	Buckle SW RH and Seat Belt Warning Occupant Detection Sensor	
A 8	ABS Speed Sensor Front LH	90980-11074	C 1	Camshaft Position Sensor	90980-10947
A 9	ABS Speed Sensor Front RH		C 2	Camshaft Timing Oil Control Valve	90980-11162
A10	Accel Position Sensor (2JZ-GE)	90980-11150	C 3	Check Connector	90980-11195
	Accel Position Sensor (3UZ-FE)	90980-11144	C 4	Crankshaft Position Sensor (2JZ-GE)	90980-10947
A11	Air Flow Meter	90980-11317		Crankshaft Position Sensor (3UZ-FE)	90980-11162
A12	Airbag Sensor Front LH	90980-11856	C 5	CD Automatic Changer	90980-11923
A13	Airbag Sensor Front RH		C 6	Center Airbag Sensor Assembly	90980-11873
A14	Alternator	90980-09218	C 7	Center Airbag Sensor Assembly	90980-11872
A15	Alternator	90980-11349	C 8	Center Airbag Sensor Assembly	90980-11871
A16	A/C Control Assembly	90980-11392	C 9	Cigarette Lighter	90980-11606
A17	A/C Control Assembly	90980-11391	C10	Clock	90980-10799
A18	A/C Room Temp. Sensor (LHD)	90980-10825	C11	Combination Meter	90980-11195
	A/C Room Temp. Sensor (RHD)	90980-11918	C12	Combination Meter	90980-11194
A19	A/C Solar Sensor	90980-11053	C13	Combination SW (Europe, G.G.G.)	90980-11595
A20	A/C Thermistor	90980-10825		Combination SW (Australia)	90980-11671
A21	A/T Shift Position Illumination	90980-11212	C14	Combination SW	90980-11614
A22	ABS & TRC & VSC ECU	90980-11935	C15	Combination SW	90980-11616
A23	ABS & TRC & VSC ECU	90980-11476	C16	Combination SW	90980-11594
A24	ABS & TRC & VSC ECU	90980-11637	C17	Cellular Phone (Hand Set)	90980-10998
A25	ABS & TRC & VSC ECU	90980-11638	C18	Cellular Phone (Hand Set)	90980-10798
A26	ABS Deceleration Sensor	90980-11182	C19	Curtain Shield Airbag Squib LH	90980-12109
A27	Air Inlet Control Servo Motor	90980-11165	C20	Curtain Shield Airbag Squib RH	
A28	Air Mix Control Servo Motor (Driver Side)		C21	Camshaft Timing Oil Control Valve LH	90980-11162
A29	Air Mix Control Servo Motor (Front Passenger Side)		C22	Camshaft Timing Oil Control Valve RH	
A30	Air Vent Mode Control Servo Motor		D 1	Daytime Running Light Relay	90980-10807
A31	Airbag Squib (Front Passenger Airbag Assembly)	90980-11884	D 2	DLC3	90980-11665
A32	Airbag Squib (Steering Wheel Pad)	90980-10850	D 3	Diode (Luggage Door Open Detection)	90980-11071
A33	Automatic Light Control Sensor	90980-11107	D 4	Door Courtesy Light Front LH	90980-11148
A34	ABS Speed Sensor Rear LH	90980-11060	D 5	Door Courtesy Light Front RH	
A35	ABS Speed Sensor Rear RH	90980-11300	D 6	Door Courtesy Light Rear LH	
A36	Ashtray Illumination Rear LH	90981-11041	D 7	Door Courtesy Light Rear RH	
A37	Ashtray Illumination Rear RH		D 8	Door Courtesy SW Front LH	90980-11156
A38	Auto Antenna Control Relay and Motor	90980-10799	D 9	Door Courtesy SW Front RH	
B 1	Brake Fluid Level Warning SW	90980-11009	D10	Door Courtesy SW Rear LH	
B 2	Blower Motor	90980-10385	D11	Door Courtesy SW Rear RH	
B 3	Blower Motor Controller	90980-11579	D12	Door Lock Control SW LH	90980-11013
			D13	Door Lock Control SW RH	

Note: Not all of the above part numbers of the connector are established for the supply.

Nota: Toutes les références du connecteur ne sont pas définies pour la fourniture.

Code	Part Name	Part Number	Code	Part Name	Part Number
D14	Door Lock Motor and Door Lock Detection SW Rear LH	90980-11150	F14	Fuel Lid Opener Motor	90980-11150
D15	Door Lock Motor and Door Lock Detection SW Rear RH		F15	Fuel Pump and Sender	90980-11077
			F16	Fuel Pump Control ECU	90980-10862
D16	Door Lock Motor, Door Key Lock and Unlock SW and Door Lock Detection SW Front LH	90980-11858	F17	Fuel Sender (Sub)	90980-11140
			G 1	Glove Box Light	90980-11148
			G 2	Glove Box Light SW	90980-11098
D17	Door Lock Motor, Door Key Lock and Unlock SW and Door Lock Detection SW Front RH		G 3	Gateway ECU	90980-11911
			H 1	Headlight Beam Level Control Actuator LH	90980-11016
D18	Driver Door ECU	90980-11595	H 2	Headlight Beam Level Control Actuator RH	
D19	Driver Door ECU	90980-11648	H 3	Headlight Beam Level Control ECU	90980-10897
D20	Driver Door ECU	90980-11594	H 4	Headlight Beam Level Control ECU	90980-10891
D21	Driving Position Memory SW	90980-11165	H 5	Headlight Beam Level Control Motor	90980-11144
D22	Door Lock Motor and SW Front LH	90980-11539	H 6	Headlight Cleaner Control Relay	90980-10939
D23	Door Lock Motor and SW Front RH		H 7	Headlight Cleaner Motor	90980-11410
D24	Door Lock Motor and SW Rear LH	90980-11535	H 8	Headlight Control ECU LH	90980-11255
D25	Door Lock Motor and SW Rear RH		H 9	Headlight Control ECU RH	
E 1	ECT Solenoid	90980-11151	H10	Headlight LH (High)	90980-11095
E 2	Engine and ECT ECU (2JZ-GE)	90980-11421	H11	Headlight LH (Low)	90980-11096
	Engine and ECT ECU (3UZ-FE)	90980-12144	H12	Headlight RH (High)	90980-11095
E 3	Engine and ECT ECU (2JZ-GE)	90980-11476	H13	Headlight RH (Low)	90980-11096
	Engine and ECT ECU (3UZ-FE)	90980-12145	H14	Heated Oxygen Sensor (Bank 1 Sensor 1) (2JZ-GE)	90980-11028
E 4	Engine and ECT ECU (2JZ-GE)	90980-11586		Heated Oxygen Sensor (Bank 1 Sensor 1) (3UZ-FE)	90980-10869
	Engine and ECT ECU (3UZ-FE)	90980-12143	H15	Heated Oxygen Sensor (Bank 1 Sensor 2)	90980-11028
E 5	Engine and ECT ECU (2JZ-GE)	90980-11637	H16	Heated Oxygen Sensor (Bank 2 Sensor 1)	90980-10869
	Engine and ECT ECU (3UZ-FE)	90980-12146	H17	Height Control Sensor (Front)	90980-11929
E 6	Engine and ECT ECU (2JZ-GE)	90980-11638	H18	Horn LH	90980-10619
	Engine and ECT ECU (3UZ-FE)	90980-12142	H19	Horn RH	
E 7	Engine and ECT ECU (2JZ-GE)	90980-11423	H20	Hazard SW	90980-10801
E 8	Engine Hood Courtesy SW	90980-11189	H21	Headlight Beam Level Control SW	90980-10996
E 9	Engine Oil Level Sensor	90980-11235	H22	Headlight Cleaner SW (LHD)	90980-10797
E10	Exhaust Gas Sensor	90980-10831		Headlight Cleaner SW (RHD)	90980-10601
E11	ECT Pattern Select SW	90980-11165	H23	Heated Oxygen Sensor (Bank 2 Sensor 2)	90980-11028
F 1	Front Fog Light LH	90980-11096	H24	Height Control Sensor (Rear)	90980-11298
F 2	Front Fog Light RH		H25	High Mounted Stop Light (Bulb Type)	90980-10908
F 3	Front Side Turn Signal Light LH	90980-11162	H26	High Mounted Stop Light (LED Type)	90980-11368
F 4	Front Side Turn Signal Light RH		I 1	Igniter	90980-11653
F 5	Front Turn Signal and Clearance Light LH	90980-10942	I 2	Ignition Coil No.1	90980-11246
F 6	Front Turn Signal and Clearance Light RH		I 3	Ignition Coil No.2	
F 7	Front Wiper Motor	90980-11599	I 4	Ignition Coil No.3	
F 8	Fuel Lid Opener SW	90980-10825	I 5	Injector No.1	
F 9	Front Door Speaker LH	90980-10935	I 6	Injector No.2	
F10	Front Door Speaker RH		I 7	Injector No.3	
F11	Front Passenger Door ECU	90980-11594	I 8	Injector No.4	
F12	Front Passenger Door ECU	90980-11648			
F13	Front Passenger Door ECU	90980-11595			

Nota : No todos los números de las partes del conector indicados arriba están dispuestos para el suministro.

Anmerkung : Nicht alle der obenerwähnten Teile-Nummern der Stecker werden für die Lieferung etabliert.

H PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
I 9	Injector No.5	90980-11153	J29	Junction Connector	90980-10803
I10	Injector No.6		J30	Junction Connector	90980-11396
I11	Ignition Key Cylinder Light	90980-10906	J31	Junction Connector	90980-11915
I12	Ignition SW	90980-11615	J32	Junction Connector	90980-10976
I13	Inner Mirror	90980-11186	J33	Junction Connector	90980-11398
I14	Interior Light Rear LH	90980-11187	J34	Junction Connector	90980-10803
I15	Interior Light Rear RH		J35	Junction Connector	90980-11542
I16	Ignition Coil and Igniter No.1	90980-11885	J36	Junction Connector	90980-11915
I17	Ignition Coil and Igniter No.2		J37	Junction Connector	90980-10803
I18	Ignition Coil and Igniter No.3		J38	Junction Connector	90980-11915
I19	Ignition Coil and Igniter No.4		J39	Junction Connector	90980-11542
I20	Ignition Coil and Igniter No.5		J40	Junction Connector	90980-10803
I21	Ignition Coil and Igniter No.6		J41	Junction Connector	90980-11915
I22	Ignition Coil and Igniter No.7		J42	Junction Connector	90980-10976
I23	Ignition Coil and Igniter No.8		J43	Junction Connector	90980-11542
I24	Injector No.7	90980-11153	J44	Junction Connector	90980-10976
I25	Injector No.8		J45	Junction Connector	
J 1	Junction Connector	90980-10803	J46	Junction Connector	90980-10803
J 2	Junction Connector	90980-11542	J47	Junction Connector	
J 3	Junction Connector	90980-11661	J48	Junction Connector	
J 4	Junction Connector		J49	Junction Connector	90980-11542
J 5	Junction Connector	90980-10803	K 1	Knock Sensor 1	90980-11166
J 6	Junction Connector	90980-11398	K 2	Knock Sensor 2	
J 7	Junction Connector	90980-11542	K 3	Kick Down SW	90980-11156
J 8	Junction Connector	90980-10976	L 1	Luggage Compartment Door Opener SW	90980-10860
J 9	Junction Connector	90980-11915	L 2	License Plate Light LH	90980-11148
J10	Junction Connector	90980-11542	L 3	License Plate Light RH	
J11	Junction Connector	90980-11398	L 4	Light Failure Sensor	90980-10803
J12	Junction Connector	90980-10802	L 5	Luggage Compartment Door Courtesy SW and Opener Motor	90980-10825
J13	Junction Connector	90980-11915	L 6	Luggage Compartment Door Key Unlock SW	90980-11212
J14	Junction Connector	90980-11542	L 7	Luggage Compartment Light	90980-11148
J15	Junction Connector	90980-11915	L 8	Lumbar Support Control SW (Driver's Seat)	90980-10601
J16	Junction Connector	90980-11542	L 9	Lumbar Support Control SW (Front Passenger's Seat)	
J17	Junction Connector	90980-11539	M 1	Master Cylinder Pressure Sensor	90980-11451
J18	Junction Connector	90980-10803	M 2	Multi-Display	90980-10799
J19	Junction Connector	90980-11542	M 3	Multi-Display	90980-11911
J20	Junction Connector		M 4	Moon Roof Control ECU	90980-10997
J21	Junction Connector	90980-10976	M 5	Moon Roof Control SW	90980-11488
J22	Junction Connector		M 6	Multi-Display	90980-11923
J23	Junction Connector	90980-10803	M 7	Mirror Retractor SW	90980-11090
J24	Junction Connector		N 1	Neutral Start SW	90980-11784
J25	Junction Connector	90980-10803	N 2	Noise Filter (Ignition)	90980-10843
J26	Junction Connector	90980-11542			
J27	Junction Connector	90980-11661			
J28	Junction Connector				

Note: Not all of the above part numbers of the connector are established for the supply.

Nota: Toutes les références du connecteur ne sont pas définies pour la fourniture.

Code	Part Name	Part Number	Code	Part Name	Part Number
N 3	Navigation ECU	90980-11923	P31	Power Seat Position Sensor (Driver's Seat Rear Vertical Control)	90980-10908
N 4	Navigation ECU	90980-11973	P32	Power Seat Position Sensor (Driver's Seat Reclining Control)	
N 5	Noise Filter (Rear Window Defogger)	90980-11259	P33	Power Seat Position Sensor (Driver's Seat Slide Control)	
N 6	Noise Filter (Ignition No.1)	90980-10843	P34	Power Steering Oil Pressure Sensor	90980-10845
N 7	Noise Filter (Ignition No.2)		R 1	Radiator Fan Motor	90980-10928
O 1	O/D Direct Clutch Speed Sensor	90980-11156	R 2	Radio and Player (Europe)	90980-12038
O 2	Oil Pressure SW	90980-11363		Radio and Player (Except Europe)	90980-10996
P 2	PPS Solenoid	90980-11003	R 3	Radio and Player (Europe)	90980-10803
P 3	Parking Brake SW	90980-10871		Radio and Player (Except Europe)	90980-10997
P 4	Power Outlet	90980-10760	R 4	Radio and Player (Except Europe)	90980-11165
P 5	PPS ECU	90980-10797	R 5	Rear Fog Light Relay	82660-20340
P 6	Personal Light	90980-11187	R 6	Rear Fog Light SW	90980-11090
P 7	Power Window Control SW Front LH	90980-10797	R 7	Remote Control Mirror SW	90980-11657
P 8	Power Window Control SW Front RH		R 8	Rheostat	90980-11165
P 9	Power Window Control SW Rear LH		R 9	Rear Combination Light LH	90980-11399
P10	Power Window Control SW Rear RH		R10	Rear Combination Light LH	90980-11587
P11	Power Window Master SW	90980-11469	R11	Rear Combination Light RH	90980-11399
P12	Power Window Motor Front LH	90980-11011	R12	Rear Combination Light RH	90980-11587
P13	Power Window Motor Front RH		R13	Rear Door LH ECU	90980-11877
P14	Pretensioner LH	90980-11862	R14	Rear Door RH ECU	
P15	Pretensioner RH		R15	Rear Door Speaker LH	90980-10935
P16	Power Seat Control SW (Driver's Seat)	90980-10997	R16	Rear Door Speaker RH	
P17	Power Seat Control SW (Front Passenger's Seat)		R17	Remote Control Mirror LH	90980-11590
P18	Power Seat ECU	90980-11527	R18	Remote Control Mirror RH	90980-11690
P19	Power Seat ECU	90980-11502	S 1	Speed Sensor (ECT)	90980-11156
P20	Power Seat Motor (Driver's Seat Front Vertical Control)	90980-10825	S 2	Starter	90980-11400
P21	Power Seat Motor (Driver's Seat Lumbar Support Control)		S 3	Starter	—
P22	Power Seat Motor (Driver's Seat Rear Vertical Control)		S 4	Seat Heater SW	90980-10797
P23	Power Seat Motor (Driver's Seat Reclining Control)		S 5	Shift Lock Control ECU	90980-11450
P24	Power Seat Motor (Driver's Seat Slide Control)		S 6	Step Light LH	90980-12110
P25	Power Seat Motor (Front Passenger's Seat Front Vertical Control)		S 7	Step Light RH	
P26	Power Seat Motor (Front Passenger's Seat Lumbar Support Control)		S 8	Stereo Component Amplifier	90980-10803
P27	Power Seat Motor (Front Passenger's Seat Rear Vertical Control)		S 9	Stereo Component Amplifier	90980-10799
P28	Power Seat Motor (Front Passenger's Seat Reclining Control)		S10	Stereo Component Amplifier	90980-10997
P29	Power Seat Motor (Front Passenger's Seat Slide Control)		S11	Stereo Component Amplifier	90980-10998
P30	Power Seat Position Sensor (Driver's Seat Front Vertical Control)	90980-11296	S12	Stop Light SW	90980-11118
			S13	Side Airbag Sensor LH	90980-11857
			S14	Side Airbag Sensor RH	
			S16	Seat Heater (Driver's Seat Back)	90980-10825
			S17	Seat Heater (Driver's Seat Cushion)	
			S18	Seat Heater (Front Passenger's Seat Back)	

Nota : No todos los números de las partes del conector indicados arriba están dispuestos para el suministro.

Anmerkung: Nicht alle der obenerwähnten Teile-Nummern der Stecker werden für die Lieferung etabliert.

H PART NUMBER OF CONNECTORS

[illegible]

Note: Not all of the above part numbers of the connector are established for the supply.

Nota: Toutes les références du connecteur ne sont pas définies pour la fourniture.

Anmerkung: Nicht alle der obenerwähnten Teile-Nummern der Stecker werden für die Lieferung etabliert.