

## DIAGNOSTIC TROUBLE CODE CHART

If a malfunction code is displayed during the DTC check, check the circuit listed for that code in the table below. (Proceed to the page given for that circuit.)

DTC No. (See Page)	Detection Item	Trouble Area	SRS Warning Light
B0100/13 (DI-398)	• Short in D squib circuit	<ul style="list-style-type: none"> <li>Steering wheel pad (Squib)</li> <li>Spiral cable</li> <li>Airbag sensor assembly</li> <li>Wire harness</li> </ul>	ON
B0101/14 (DI-403)	• Open in D squib circuit	<ul style="list-style-type: none"> <li>Steering wheel pad (Squib)</li> <li>Spiral cable</li> <li>Airbag sensor assembly</li> <li>Wire harness</li> </ul>	ON
B0102/11 (DI-407)	• Short in D and P squib circuits (to ground)	<ul style="list-style-type: none"> <li>Steering wheel pad (Squib)</li> <li>Front passenger airbag assembly (Squib)</li> <li>Spiral cable</li> <li>Airbag sensor assembly</li> <li>Wire harness</li> </ul>	ON
B0103/12 (DI-414)	• Short in D and P squib circuits (to B+)	<ul style="list-style-type: none"> <li>Steering wheel pad (Squib)</li> <li>Front passenger airbag assembly (Squib)</li> <li>Spiral cable</li> <li>Airbag sensor assembly</li> <li>Wire harness</li> </ul>	ON
B0105/53 (DI-420)	• Short in P squib circuit	<ul style="list-style-type: none"> <li>Front Passenger airbag assembly (Squib)</li> <li>Airbag sensor assembly</li> <li>Wire harness</li> </ul>	ON
B0106/54 (DI-424)	• Open in P squib circuit	<ul style="list-style-type: none"> <li>Front Passenger airbag assembly (Squib)</li> <li>Airbag sensor assembly</li> <li>Wire harness</li> </ul>	ON
B0110/43 (DI-427)	• Short in side squib (RH) circuit	<ul style="list-style-type: none"> <li>Side airbag assembly RH (Squib)</li> <li>Airbag sensor assembly</li> <li>Wire harness</li> </ul>	ON
B0111/44 (DI-431)	• Open in side squib (RH) circuit	<ul style="list-style-type: none"> <li>Side airbag assembly RH (Squib)</li> <li>Airbag sensor assembly</li> <li>Wire harness</li> </ul>	ON
B0112/41 (DI-434)	• Short in side squib (RH) circuit (to ground)	<ul style="list-style-type: none"> <li>Side airbag assembly RH (Squib)</li> <li>Airbag sensor assembly</li> <li>Wire harness</li> </ul>	ON
B0113/42 (DI-437)	• Short in side squib (RH) circuit (to B+)	<ul style="list-style-type: none"> <li>Side airbag assembly RH (Squib)</li> <li>Airbag sensor assembly</li> <li>Wire harness</li> </ul>	ON
B0115/47 (DI-440)	• Short in side squib (LH) circuit	<ul style="list-style-type: none"> <li>Side airbag assembly LH (Squib)</li> <li>Airbag sensor assembly</li> <li>Wire harness</li> </ul>	ON
B0116/48 (DI-444)	• Open in side squib (LH) circuit	<ul style="list-style-type: none"> <li>Side airbag assembly LH (Squib)</li> <li>Airbag sensor assembly</li> <li>Wire harness</li> </ul>	ON
B0117/45 (DI-447)	• Short in side squib (LH) circuit (to ground)	<ul style="list-style-type: none"> <li>Side airbag assembly LH (Squib)</li> <li>Airbag sensor assembly</li> <li>Wire harness</li> </ul>	ON
B0118/46 (DI-450)	• Short in side squib (LH) circuit (to B+)	<ul style="list-style-type: none"> <li>Side airbag assembly LH (Squib)</li> <li>Airbag sensor assembly</li> <li>Wire harness</li> </ul>	ON

DTC No. (See Page)	Detection Item	Trouble Area	SRS Warning Light
B0130/63 (DI-453)	• Short in P/T squib (RH) circuit	• Seat belt pretensioner (RH) (Squib) • Airbag sensor assembly • Wire harness	ON
B0131/64 (DI-457)	• Open in P/T squib (RH) circuit	• Seat belt pretensioner (RH) (Squib) • Airbag sensor assembly • Wire harness	ON
B0133/62 (DI-460)	• Short in D, P, Side and P/T squib circuits (to B+)	• Steering wheel pad (Squib) • Front passenger airbag assembly (Squib) • Side airbag assemblies (Squib) • Seat belt pretensioners (Squib) • Airbag sensor assembly	ON
B0135/73 (DI-466)	• Short in P/T squib (LH) circuit	• Seat belt pretensioner (LH) (Squib) • Airbag sensor assembly • Wire harness	ON
B0136/74 (DI-470)	• Open in P/T squib (LH) circuit	• Seat belt pretensioner (LH) (Squib) • Airbag sensor assembly • Wire harness	ON
B0137/61 (DI-473)	• Short in P/T squib circuit (to ground)	• Seat belt pretensioner (Squib) • Airbag sensor assembly • Wire harness	ON
B1100/31 (DI-478)	• Airbag sensor assembly malfunction	• Airbag sensor assembly	ON
B1140/32 (DI-480)	• Side airbag sensor assembly (RH) malfunction	• Side airbag sensor assembly (RH) • Wire harness	ON
B1141/33 (DI-486)	• Side airbag sensor assembly (LH) malfunction	• Side airbag sensor assembly (LH) • Wire harness	ON
B1156/15 (DI-492)	• Front airbag sensor assembly (RH) malfunction	• Front airbag sensor assembly (RH) • Airbag sensor assembly • Wire harness	ON
B1157/15 (DI-492)			
B1158/16 (DI-496)	• Front airbag sensor assembly (LH) malfunction	• Front airbag sensor assembly (LH) • Airbag sensor assembly • Wire harness	ON
B1159/16 (DI-496)			
Normal (DI-503)	• System normal	–	OFF
	• Voltage source drop	• Battery • Airbag sensor assembly	ON

## HINT:

- When the SRS warning light remains lit up and the DTC is the normal code, this means a source voltage drops.  
This malfunction is not stored in memory by the center airbag sensor assembly and If the power source voltage returns to normal, after approx. 10 seconds the SRS warning light will automatically go out.
- When 2 or more codes are indicated, the lowest numbered code will appear first.
- If a code not listed in the chart is displayed, the center airbag sensor assembly is faulty.