

36. No power coming in.

INSPECTION PROCEDURE

1 Is tape player operating normally?

Yes

Radio assembly faulty.

No

2 Check if RADIO No. 1 fuse is OK?

NG

Replace fuse.

OK

3 Is power supplied to ACC terminal of power amplifier?

No

ACC wire harness faulty.

YES

4 Check if RADIO No. 1 fuse is OK?

No

Replace fuse.

YES

5 Is power supplied to +B terminal of power amplifier?

No

+B wire harness faulty.

YES

6 Check if GND (wire harness side) of power amplifier grounded normally?

NG

Ground faulty.

OK

7 Is power supplied to ACC terminal of radio assembly?

No

Power amplifier or wire harness faulty.

YES

8 Is power supplied to +B terminal of radio assembly?

No

Power amplifier or wire harness faulty.

YES

9**Check if GND (wire harness side) of radio assembly grounded normally?****NG****Ground faulty.****OK****Radio assembly faulty.**