

REPLACEMENT

REPLACEMENT REQUIREMENTS

In the following cases, replace the side airbag assembly or seat cover.

- ☐ If the side airbag has been deployed.
- ☐ If the side airbag assembly has been found to be faulty in troubleshooting.
- ☐ If the side airbag assembly or seat cover has cuts and the frayed on seams during the check in item.
(See page RS-42)
- ☐ If the side airbag assembly or seat cover has been found to be faulty during the check in item.
(See page RS-42)
- ☐ If the side airbag assembly has been dropped.

CAUTION:

For removal and installation of the side airbag assembly, see page RS-40 and RS-50. Be sure to follow the correct procedure.