

FI0XD-01

- Always use new gaskets when replacing the fuel tank or component parts.
- Apply the proper torque to all parts tightened

