

TAILLIGHT (LHD)

SYSTEM OUTLINE

When the light control SW is turned to the **TAIL** or **HEAD** position, the signal is input to **TERMINAL TAIL** of the body ECU No.2. This activates the body ECU No.2 to flow the current from the battery into the **ALT** fuse, tail relay (Coil side), **TERMINAL TRLY** of the body ECU No.2 to **GROUND** in that order to turn on the tail relay. The current flows from the **TAIL** fuse into the front clearance lights, license plate lights, **TERMINAL 5** of the light failure sensor to **TERMINAL 7** and **12** to taillights in that order to turn on each light.

TAILLIGHT DISCONNECTION WARNING

If any taillight wiring is faulty when the ignition SW is turned to the **ON** position with the light control SW set at **TAIL** or **HEAD**, the light failure sensor detects a voltage difference and inputs the signal to **TERMINAL LF** of the body ECU No.2. The body ECU No.2 is activated to turn on the rear light warning light in the combination meter to warn the driver.

SERVICE HINTS

C13 LIGHT CONTROL SW [COMB. SW]

15-16 : Closed with light control SW at **TAIL** or **HEAD** position

L4 LIGHT FAILURE SENSOR

8-GROUND : Approx. **12** volts with ignition SW at **ON** or **ST** position

5-GROUND : Approx. **12** volts with light control SW at **TAIL** or **HEAD** position

11-GROUND : Always continuity

○ : PARTS LOCATION

Code		See Page	Code	See Page	Code	See Page
B6	A	72 (LHD)	J8	74 (LHD)	L3	78 (LHD)
C11	A	72 (LHD)	J10	74 (LHD)	L4	78 (LHD)
C12	B	72 (LHD)	J15	74 (LHD)	R9	78 (LHD)
C13		72 (LHD)	J18	74 (LHD)	R10	78 (LHD)
D1		72 (LHD)	J20	78 (LHD)	R11	78 (LHD)
F5		68 (LHD)	J21	78 (LHD)	R12	78 (LHD)
F6		68 (LHD)	L2	78 (LHD)		

○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	54 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	58 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1B	58 (LHD)	Cowl Wire and Driver Side J/B (Left Kick Panel)
1D	58 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1E	58 (LHD)	Floor No.2 Wire and Driver Side J/B (Left Kick Panel)
1F	58 (LHD)	Cowl Wire and Driver Side J/B (Left Kick Panel)
1G	59 (LHD)	
1H		

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC1	98 (LHD)	Floor No.2 Wire and Cowl Wire (Left Kick Panel)
IE1	98 (LHD)	Instrument Panel Wire and Cowl Wire (Left Side of the Steering Column)
II2	100 (LHD)	Engine Room Main Wire and Cowl Wire (Near the Passenger Side R/B)









: GROUND POINTS

Code	See Page	Ground Points Location
EA	96 (LHD)	Right Fender
EB	96 (LHD)	Left Fender
IF	98 (LHD)	Left Kick Panel
II	98 (LHD)	Right Side of the Cowl Panel
BK	102 (LHD)	Quarter Panel LH




: SPLICE POINTS


Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
B4	102 (LHD)	Floor No.2 Wire	B5	102 (LHD)	Floor No.2 Wire




(Hint : See Page 7, 23, 39)




(Hint : See Page 7, 23, 39)




(Hint : See Page 7, 23, 39)



(Hint : See Page 7, 23, 39)



(Hint : See Page 7, 23, 39)



(Hint : See Page 7, 23, 39)

