



VEHICLE SPEED SENSOR ON-VEHICLE REPAIR

AT06K-02

1. **DISCONNECT VEHICLE SPEED SENSOR CONNECTOR**
2. **REMOVE VEHICLE SPEED SENSOR**
 - (a) Remove the bolt and vehicle speed sensor.
 - (b) Remove the O-ring from the sensor.
3. **INSTALL VEHICLE SPEED SENSOR**
 - (a) Coat a new O-ring with ATF and install it to the speed sensor.
 - (b) Install the speed sensor with the bolt.
Torque: 5.4 N·m (55 kgf·cm, 48 in.·lbf)
4. **CONNECT VEHICLE SPEED SENSOR CONNECTOR**