

## REMOVAL

1. DRAIN ENGINE COOLANT
2. REMOVE AIR CLEANER INLET
3. REMOVE AIR CLEANER AND AIR FLOW METER ASSEMBLY
4. REMOVE ELECTRIC COOLING FAN
  - (a) Disconnect these parts:
    - Upper radiator hose from radiator
    - ECU outlet duct from ECU box
    - Wire for electric cooling fan from clamp on electric cooling fan
    - 2 electric cooling fan connectors
    - Radiator reservoir hose from radiator
  - (b) Remove the 6 bolts and electric cooling fan.

