

REMOVAL

1. DRAIN ENGINE COOLANT FROM RADIATOR

HINT:

It is not necessary to drain out all coolant.

2. REMOVE THESE PARTS:

- (a) Air cleaner duct
- (b) Air cleaner assembly
- (c) Radiator reservoir tank cap

3. DISCONNECT THESE PARTS:

- (a) Upper radiator hose
- (b) Reservoir hose

4. REMOVE COOLING FAN

- (a) Disconnect the connectors.
- (b) Remove the 6 bolts cooling fan.