


























# SUSPENSION AND AXLE














## SST (Special Service Tools)

PP0T1-02














	09223-46011	Crankshaft Front Oil Seal Replacer	Rear differential
	09223-56010	Crankshaft Rear Oil Seal Replacer	Rear differential
	09229-55010	Oil Cooler Relief Valve Wrench	Rear differential
	09240-00020	Wire Gauge Set	Rear drive shaft
	(09242-00080)	Wire Gauge	
	09250-10011	Replacer Set "A"	Rear differential
	(09255-10011)	Crankshaft Rear Bearing Remover & Replacer	
	09308-00010	Oil Seal Puller	Front axle Rear differential
	09309-36010	Transmission Rear Bearing Replacer	Front axle Rear drive shaft
	09316-12010	Transfer Bearing Replacer	Differential mounting cushion
	09316-60011	Transmission & Transfer Bearing Replacer	Front axle Rear differential
	(09316-00011)	Replacer Pipe	









## PREPARATION – SUSPENSION AND AXLE

	(09316-00041) Replacer "C"	
	(09316-00071) Replacer "F"	
	09325-40010 Transmission Oil Plug	Rear differential
	09330-00021 Companion Flange Holding Tool	Rear differential
	09502-12010 Differential Bearing Replacer	Rear drive shaft Rear differential
	09502-24010 Bearing Replacer	Rear differential
	09520-00031 Rear Axle Shaft Puller	Rear axle
	09520-24010 Differential Side Gear Shaft Puller	Rear differential
	09521-24010 Drive Shaft Boot Clamping Tool	Rear drive shaft
	09527-17011 Rear Axle Shaft Bearing Remover	Rear axle
	09570-24010 Differential Mounting Cushion Remover & Replacer	Differential mounting cushion
	09608-04031 Front Hub Inner Bearing Cone Replacer	Rear differential
	09608-32010 Steering Knuckle Oil Seal Replacer	Front axle Rear differential

	09610-20012 Pitman Arm Puller	Front axle Front suspension Rear axle
	09628-10011 Ball Joint Puller	Front wheel hub bolt Rear wheel hub bolt
	09628-62011 Ball Joint Puller	Front suspension Rear axle Rear suspension
	09710-30050 Suspension Arm Bushing Replacer	Rear differential
	09726-12023 Lower Suspension Arm Bushing Remover & Replacer	Rear drive shaft
	(09726-01031) Spacer	
	09727-30021 Coil Spring Compressor	Front suspension Rear suspension
	09950-00020 Bearing Remover	Rear axle Rear differential
	09950-40011 Puller B Set	Front axle Rear axle Rear differential
	(09951-04020) Hanger 200	
	(09952-04010) Slide Arm	
	(09953-04020) Center Bolt 150	
	(09953-04030) Center Bolt 200	

## PREPARATION - SUSPENSION AND AXLE

	(09954-04020) Arm 100	
	(09955-04040) Claw No.4	
	(09955-04060) Claw No.6	
	(09957-04010) Attachment	
	(09958-04010) Holder	
	09950-60010 Replacer Set	Front axle Rear axle Rear differential
	(09951-00450) Replacer 45	
	(09951-00480) Replacer 48	
	(09951-00510) Replacer 51	
	(09951-00560) Replacer 56	
	(09951-00650) Replacer 65	
	09950-60020 Replacer Set No.2	Front axle Rear axle Rear differential
	(09951-00710) Replacer 71	

	(09951-00720) Replacer 72	
	(09951-00780) Replacer 78	
	(09951-00810) Replacer 81	
	(09951-00890) Replacer 89	
	(09951-01030) Replacer 103	
	09950-70010 Handle Set	Front axle Rear axle Rear differential
	(09951-07100) Handle 100	
	(09951-07150) Handle 150	