


**Wire Harness Side:**

F03098


**INSPECTION**

1. **INSPECT ECU-IG FUSE (Engine room No.1 (R/B))**  
(See page BE-21)
2. **INSPECT PPS ECU CIRCUIT**
  - (a) Disconnect the PPS ECU connector.
  - (b) Inspect the connector on wire harness side, as shown in the illustration.

Tester Connection	Condition	Specified Condition
4 - Body Ground	Ignition switch ON	Battery voltage
6 - Body Ground	Ignition switch ON	Continuity
*5 - 6	Ignition switch ON. Spin the rear wheel on one side with jacking or lifting UP.	0 $\rightarrow$ $\infty$ $\rightarrow$ 0 $\rightarrow$ $\infty$ $\rightarrow$

If the circuit is not as specified, check and replace the wire harness.

\*If the circuit is not as specified, inspect the speed sensor.




F03735

**3. INSPECT PPS SOLENOID VALVE**

- (a) Disconnect the PPS solenoid connector.
- (b) Measure the resistance between the terminals of the solenoid 1 and 2.

**Resistance: 6 – 11  $\Omega$**

If it is not as specified, replace the pressure control valve with the solenoid valve.




- (c) Check the PPS solenoid operation.
- (1) Connect the battery positive terminal to the solenoid terminal 1.
  - (2) Connect the battery negative terminal to the solenoid terminal 2.
  - (3) Check that the solenoid makes a "clicks" sound.

If it is faulty, replace the pressure control valve with the solenoid valve.

**NOTICE:**

- Do not apply voltage for more than 30 seconds to avoid burning out the solenoid.
- If repeating this step, wait until the solenoid cools down enough that it can be touched by hand.

- (d) Connect the PPS solenoid connector.




- (e) Inspect the PPS solenoid valve circuit.
- (1) Disconnect the PPS ECU connector.
  - (2) Check continuity between the terminals of the connector on wire harness side, as shown in the illustration.

Tester connection	Specified condition
1 – 6	No continuity
2 – 6	No continuity

If it is not as specified, repair or replace wire harness or connector.


- (3) Connect the PPS ECU connector.



**4. INSPECT PPS ECU**

- (a) Jack up the vehicle and support it on stands.
- (b) Start the engine.
- (c) Measure the voltage of ECU.
  - (1) Using a voltmeter, measure the voltage between ECU terminals 2 and 6 while the engine is idling.

**Standard voltage: 0.19 – 0.24 V**



- (2) Place the transmission in gear and while running at about 62 mph (100 km/h), measure the voltage between ECU terminals 2 and 6.

**Standard voltage: 0.07 – 0.14 V**

If no voltage, try another ECU for LEXUS GS300.

- (d) Lower the vehicle.