

INSTALLATION

Installation is in the reverse order of removal (See page SA-18).

HINT:

After installation, check the ABS speed sensor signal (See page DI-210) and front wheel alignment (See page SA-4).