


F01850

## INSPECTION

### 1. INSPECT STEERING LOCK OPERATION

Check that the steering lock mechanism operates properly.



F01851

### 2. IF NECESSARY, REPLACE KEY CYLINDER

- Place the ignition key at the ACC position.
- Push down the stop pin with a screwdriver, and pull out the cylinder.
- Install a new cylinder.

HINT:

Make sure the key is at the ACC position.

### 3. INSPECT IGNITION SWITCH

(See page BE-31)

### 4. IF NECESSARY, REPLACE IGNITION SWITCH

- remove the 2 screws.
- Install a new switch with the 2 screws.

### 5. INSPECT KEY UNLOCK WARNING SWITCH

(See page BE-31)

### 6. INSPECT KEY INTERLOCK SOLENOID

(See page AT-13)

### 7. IF NECESSARY, REPLACE KEY UNLOCK WARNING SWITCH WITH KEY INTERLOCK SOLENOID

- Remove the 2 screws.
- Install a new switch with solenoid with the 2 screws.

### 8. INSPECT TRANSPONDER KEY COIL

(See page BE-253)

### 9. IF NECESSARY, REPLACE TRANSPONDER KEY COIL

### 10. IF NECESSARY, REPLACE TRANSPONDER KEY AMPLIFIER

- Remove the screw.
- Install a new key amplifier with the screw.