

Diagram illustrating the components of the engine under cover assembly, including the PS Pump, PS Pump Bracket, Suction Hose, Discharge Hose, Compressor, and Engine Under Cover. The diagram shows the assembly sequence and the location of various parts, including bolts, nuts, and O-rings.

Key components and their associated part numbers (in parentheses):

- PS Pump
- PS Pump Bracket
- Suction Hose
- Discharge Hose
- Compressor
- Engine Under Cover
- Compressor Bracket
- Drive Belt
- O-Ring

Part numbers shown in the diagram:

- 52 (530, 38)
- 58 (590, 43)
- 10 (100, 7)
- 26 (265, 19)
- 52 (530, 38)

13.2 (135, 9)

Pressure Plate

Shim

Rotor

Stator

◆ Snap Ring

Compressor

- ◆ Non-reusable part

G.C.C. Countries:

