

<b>DTC</b>	<b>P1335/12,13</b>	<b>Crankshaft Position Sensor Circuit Malfunction (during engine running)</b>
------------	--------------------	---

## CIRCUIT DESCRIPTION

Refer to DTC P0335/12, 13 (Crankshaft Position Sensor Circuit Malfunction) on [page DI-68](#).

DTC No.	DTC Detecting Condition	Trouble Area
P1335/13	No crankshaft position sensor signal to engine ECU with engine speed 1,000 rpm or more	<ul style="list-style-type: none"> <li>• Open or short in crankshaft position sensor circuit</li> <li>• Crankshaft position sensor</li> <li>• Starter</li> <li>• Engine ECU</li> </ul>

## WIRING DIAGRAM

Refer to DTC P0335/12, 13 (Crankshaft Position Sensor Circuit Malfunction) on [page DI-68](#) for the WIRING DIAGRAM.

## INSPECTION PROCEDURE

HINT:

Refer to DTC P0335/12, 13 (Crankshaft Position Sensor Circuit Malfunction) on [page DI-68](#).