

PRE-CHECK

Only wireless function (Remote control) will not operate.

(If a new transmitter or a transmitter of the same type that works properly with the vehicle is not available.)

Make the vehicle in the initialized condition:

The initialized condition is the condition when the following conditions are satisfied.

- (1) Key plate has not been inserted in the ignition key cylinder.
- (2) All the doors are closed. (Door warning light is OFF.)
- (3) All the doors are locked.
- (4) Wireless door lock control switch (Buzzer switch) is ON.

Basic function check:

Under the standard operation, when repeating UNLOCK and LOCK switch 3 times or more alternately, check the UNLOCK-LOCK operation from 3rd time onward.

● Following procedures are standard operation.

- (1) Keep about 1 M away to the right direction from the outside handle of a driver's seat.
- (2) Face the transmitter toward the vehicle and press one of transmitter switches for about 1 sec.

<Reference>

- As of the security function, even the wireless function is normal, there may be the case that only UNLOCK operation will not work.
- As of the body customize function, if "operation twice" has been set using LEXUS hand-held tester, only driver's seat is unlocked by unlock operation performed once.

No

Yes

Transmitter LED inspection:

Check when pressing UNLOCK switch and LOCK switch under standard operation, that the transmitter LED lights up once more.

No

Yes

Normal

<Reference>

- Operative distance may differ according to an operator, the way of holding the transmitter or position.
- Because weak electric wave is used, when there is strong wave or noise in the used frequency, operation distance might be shortened.







