

SERVICE HINTS

L1 LUGGAGE COMPARTMENT DOOR OPENER SW

1-2 : Closed with the luggage compartment door open

B5 (A) BODY ECU NO.1

1-GROUND : Approx. **12** volts with ignition SW at **ON** or **ST** position

4, 8-GROUND : Always approx. **12** volts

(A)15-GROUND : Approx. **12** volts with ignition SW at **ACC** or **ON** position

(A)17-GROUND : Continuity with luggage compartment door open

: PARTS LOCATION

| Code | | See Page | Code | See Page | Code | See Page |
|------|---|----------|------|----------|------|----------|
| B5 | A | 86 (RHD) | J37 | 88 (RHD) | J42 | 88 (RHD) |
| J31 | | 88 (RHD) | J38 | 88 (RHD) | L1 | 88 (RHD) |
| J32 | | 88 (RHD) | J41 | 88 (RHD) | L5 | 90 (RHD) |

: RELAY BLOCKS

| Code | See Page | Relay Blocks (Relay Block Location) |
|------|----------|--|
| 1 | 54 (RHD) | Engine Room No.1 R/B (Engine Compartment Left) |

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

| Code | See Page | Junction Block and Wire Harness (Connector Location) |
|------|----------|--|
| 1H | 59 (RHD) | Cowl Wire and Driver Side J/B (Right Kick Panel) |
| 2B | 60 (RHD) | Engine Room Main Wire and Passenger Side J/B (Left Kick Panel) |
| 2F | 60 (RHD) | Cowl Wire and Passenger Side J/B (Left Kick Panel) |
| 2G | 61 (RHD) | |

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

| Code | See Page | Joining Wire Harness and Wire Harness (Connector Location) |
|------|-----------|--|
| IC1 | 108 (RHD) | Floor No.2 Wire and Cowl Wire (Left Kick Panel) |

: GROUND POINTS

| Code | See Page | Ground Points Location |
|------|-----------|------------------------------|
| IF | 108 (RHD) | Left Kick Panel |
| IG | 108 (RHD) | Behind the Combination Meter |
| II | 108 (RHD) | Cowl Side Panel RH |

LUGGAGE COMPARTMENT DOOR OPENER (RHD)

